

TPS2330/TPS2331, TPS5102 InfiniBandSM Bulk Power Evaluation Module and Interface Card

User's Guide

IMPORTANT NOTICE

Texas Instruments and its subsidiaries (TI) reserve the right to make changes to their products or to discontinue any product or service without notice, and advise customers to obtain the latest version of relevant information to verify, before placing orders, that information being relied on is current and complete. All products are sold subject to the terms and conditions of sale supplied at the time of order acknowledgment, including those pertaining to warranty, patent infringement, and limitation of liability.

TI warrants performance of its products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are utilized to the extent TI deems necessary to support this warranty. Specific testing of all parameters of each device is not necessarily performed, except those mandated by government requirements.

Customers are responsible for their applications using TI components.

In order to minimize risks associated with the customer's applications, adequate design and operating safeguards must be provided by the customer to minimize inherent or procedural hazards.

TI assumes no liability for applications assistance or customer product design. TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right of TI covering or relating to any combination, machine, or process in which such products or services might be or are used. TI's publication of information regarding any third party's products or services does not constitute TI's approval, license, warranty or endorsement thereof.

Reproduction of information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations and notices. Representation or reproduction of this information with alteration voids all warranties provided for an associated TI product or service, is an unfair and deceptive business practice, and TI is not responsible nor liable for any such use.

Resale of TI's products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service, is an unfair and deceptive business practice, and TI is not responsible nor liable for any such use.

Also see: Standard Terms and Conditions of Sale for Semiconductor Products. www.ti.com/sc/docs/stdterms.htm

Mailing Address:

Texas Instruments
Post Office Box 655303
Dallas, Texas 75265

Preface

Read This First

How to Use This Manual

This document contains the following chapters:

- ☐ Chapter 1—Introduction
- ☐ Chapter 2—InfiniBand Bulk Power EVM
- ☐ Chapter 3—Schematics of the EVM and the Interface Card
- ☐ Chapter 4—Layouts of the EVM and the Interface Card
- ☐ Chapter 5—Setup of the EVM
- ☐ Chapter 6—Test Points

FCC Warning

This equipment is intended for use in a laboratory test environment only. It generates, uses, and can radiate radio frequency energy and has not been tested for compliance with the limits of computing devices pursuant to subpart J of part 15 of FCC rules, which are designed to provide reasonable protection against radio frequency interference. Operation of this equipment in other environments may cause interference with radio communications, in which case the user at his own expense will be required to take whatever measures may be required to correct this interference.

Service Mark

InfiniBand is a service mark of InfiniBand Trade Association.

Contents

1	Introduction	1-1
2	InfiniBand Bulk-Power EVM	2-1
3	Schematics of the EVM and the Interface Card	3-1
4	Layouts of the EVM and the Interface Card	4-1
5	Setup of the EVM	5-1
6	Test Points	6-1

Figures

3-1	Schematic of the Interface Card (SLVP155)	3-2
3-2	Schematic of the InfiniBand Bulk Power Evaluation Module (EVM)	3-3
4-1	Top Layer of the Interface Card and Placement of the Components	4-2
4-2	Top Layer of the InfiniBand Bulk Power EVM and Placement of Components	4-3
5-1	Evaluation Setup of the InfiniBand Bulk Power EVM	5-2

Tables

3-1	Components on the Interface Card (SLVP155), Bill of Materials	3-5
3-2	Components on the InfiniBand Bulk Power EVM (SLVP185), Bill of Materials	3-6

Introduction

The TPS2330/TPS2331 is a Texas Instruments hot swap controller that eliminates high-frequency hot-plug or hot-removal transients, reduces inrush current, and provides overcurrent protection. The TPS5102 is a dual-channel dc-to-dc controller, designed for notebook PC power but suitable for many other dc/dc applications. The InfiniBandSM Trade Association (IBTA), led by seven computing-industry leaders and supported by more than 200 computer, network and electronics companies, is developing a new common I/O specification to deliver a channel-based, switched-fabric technology that the entire industry can adopt.

One of the core components of an InfiniBand system is an InfiniBand module or card, and a hot-swappable power-management solution is essential in each InfiniBand module/card. Using the TPS233x hot-swap controller and the TPS5102 dc/dc controller achieves the required power management specified in Infiniband Specification 1.0 released in October 2000.

The evaluation module (EVM) and interface card can help designers evaluate the devices and simulate hot-insertion and hot-removal actions under varied conditions.

Users need a dc voltage supply to test the operation of the EVM.



InfiniBand Bulk-Power EVM

The TPS2330/TPS2331 single-channel hot-swap controller uses external N-channel MOSFETs as high-side switches in power applications. The devices integrate features such as overcurrent protection, inrush current control, output-power status reporting, and separation of load transients from actual load increases, which are the critical requirements for hot-swap applications. For a detailed description of functions and characteristics of the TPS2300 and TPS2301, refer to the data sheet, literature number SLVS265A. Check data sheet and ordering information on website:

<http://focus.ti.com/docs/prod/productfolder.jhtml?genericPartNumber=TPS2331>

The TPS5102 is a dual-channel high-efficiency controller that drives a synchronous-rectifier buck converter. With PWM and skip operating modes, dead-time control, and very low quiescent current, the controller allows power to be conserved under all load conditions. For a detailed description of functions and characteristics of the TPS5102, refer to the data sheet, literature number SLVS239. Check data sheet and ordering information on website:

<http://focus.ti.com/docs/prod/productfolder.jhtml?genericPartNumber=TPS5102>

Refer to the data sheets to select appropriate peripheral components for the controllers. For different applications, a gate capacitor at the TPS2330/TPS2331 GATE output may be required to limit excessive inrush current or very heavy load. Recommended input capacitors can help hold the input voltage in the designed range.

To learn more about InfiniBand power-management requirements, users can go to www.infinibandta.org for a copy of the InfiniBand specification 1.0, and can also read the application report Power-Management Solutions for InfiniBand I/O Modules, from Texas Instruments on

<http://www.ti.com/sc/docs/psheets/abstract/apps/slva093.htm>

To assist designers in the evaluation of the hot-swap controllers, a set of evaluation modules has been developed: one is the InfiniBand bulk power EVM, and the other is an interface card.

Schematics of the EVM and the Interface Card

To demonstrate a hot-plug or hot-removal application, the evaluation system includes two boards: one is the hot-swappable InfiniBand bulk power EVM (SLVP185 board) where the TPS2331 and TPS5102 reside and control power MOSFETs; the other is an interface card (SLVP155 board) that supplies power and a control signal to the InfiniBand bulk power EVM.

Figures 3–1 and 3–2 show the schematic of the interface card and the schematic of the hot-swappable EVM, respectively.

Since the interface card was originally designed for universal application purposes, some of the components shown in the schematic above may not be on the board when shipped with this EVM kit. Refer to the bill of materials Table 3–1 for a complete components list.

When testing the EVM, set the slide switch S1 on the interface card (SVLP155) to HI (marked on the board), because the hot-swap controller TPS2331 is an active-high enabling device. The user can replace the TPS2331 with TPS2330 in order to evaluate the latter, but will need to switch S1 to LO to perform the evaluation.

Figure 3–1. Schematic of the Interface Card (SLVP155)






Figure 3–2. Schematic of the InfiniBand Bulk Power Evaluation Module (EVM) (Part 1)



3-4



The schematic for InfiniBand bulk power EVM (Figure 3–2) shows three jumpers (JP1, JP2, and JP3). JP1 is used to set the dc/dc converter stage in PWM (normal) or skip (power-saving) mode. For normal operation, short JP1, then the converter will be in PWM mode. JP2 is used to shut down the dc/dc converter when it is shorted, so this jumper should not be shorted if the dc/dc conversion is required. JP3 should be shorted for InfiniBand bulk power evaluation because the InfiniBand specification recommends the power-good signal of the hot-swap stage to enable the dc/dc converter.

A 14-V Zener diode in parallel with C25 is recommended if the backplane power is noisy or has potential high voltage spikes, higher than 14 V.

Several components along with the jumpers and test points are only for evaluation purposes and are not necessary for the hot-swap and/or dc/dc applications. Refer to the data sheets to optimize your designs.

A key is installed in the edge connector on the interface board (SLSP155) to ensure that the board can only be inserted in the correct direction.

The bills of materials (BOM) for both boards are shown in Tables 3–1 and 3–2, respectively.

Table 3–1. Components on the Interface Card (SLVP155), Bill of Materials

Ref Des	Qty	Part Number	Description	MFG	Size
C1, C3	Not used				
C2	1	LSR100/16DK125	Capacitor, tantalum, 100-μF, 16 V, 10%	NEMCO	D Case
C4, C6	Not used				
C5	1	GMK325F106ZH	Capacitor, ceramic, 10-μF, 35-V	Taiyo Yuden	1210
C7, C9	Not used				
C8	1	GRM40X7R105K16	Capacitor, ceramic, 1-μF, 16 V	MuRata	0805
J3, J4	2	3267	Connector, banana jack, uninsulated	Pomona	
J1,J2,J5, J6	Not used				
P1	1	50–22SN–11	Connector, 44-pin edge w/mtg tabs (for 0.062" PCB)	Cinch	
R1, R2	2	Std	Resistor, chip, 10 kΩ, 1/10 W, 5%	Std	1206
S1	1	EG1218	SW–1C–200 MA–SL		
TP1	1	240–345	Test point, red, 1 mm	Farnell	
TP5	1	240–333	Test point, black, 1 mm	Farnell	
TP2–TP3	Not used				
TP4,TP6	Not used				
Key	1	50–PK–3	Key for P1 (Newark #57F3275)	Cinch	
	4	534–1804	Spacer, aluminum, 4–40 female, 0.625" long	Mouser	
	4		Screw, pan head phillips, 4–40 × 0.25"		

Table 3–2. Components on the InfiniBand Bulk Power EVM (SLVP185), Bill of Materials

RefDes	Qty	Part Number	Description	MFR	Size
C7,C9,C13	3	GRM40X7R103K25	Capacitor, ceramic, 0.01 μ F, 25 V	MuRata	805
C25,C26,C28,C29	4	C0805C104K5RAC	Capacitor, ceramic, 0.1 μ F, 50 V	Kemet	805
C15	1	C0805C104K5RAC	Capacitor, ceramic, 0.1 μ F, 50 V	Kemet	805
C27	1	PCCC1832TR–ND	Capacitor, ceramic, 0.22 μ F, 25 V	Panasonic	805
C11	1	GRM40X7R105K16	Capacitor, ceramic, 1 μ F, 16 V	MuRata	805
C24	1	GRM40X7R333K25	Capacitor, ceramic, 33 nF, 16 V	MuRata	805
C10	1	GRM40X7R105K16	Capacitor, ceramic, 100 pF, 16 V	MuRata	805
C8	2	GRM33X7R221K6	Capacitor, ceramic, 220 pF, 16 V	MuRata	805
C14		GRM33X7R221K6	Capacitor, ceramic, 220 pF, 16 V	MuRata	805
C6,C16,C18,C19	4	OPEN	OPEN		805
C12,C17,C21	3	GMK316F225ZG	Capacitor, ceramic, 2.2 μ F, 35 V	Taiyo Yuden	1206
C2,C3	2	GMK325F106ZH	Capacitor, ceramic, 10 μ F, 35 V	Taiyo Yuden	1210
C20	1	GRM325F106ZH	Capacitor, ceramic, 10 μ F, 35 V	Taiyo Yuden	1210
C5	1	10TPB220M	Capacitor, POSCAP, 220 μ F, 4 V	Sanyo	D Case
C4	1	4TPB470M	Capacitor, POSCAP, 470 μ F, 4 V	Sanyo	D Case
C22,C23	2	OPEN	OPEN		D Case
C1	1	RV–35V221MH10–R	Capacitor, electrolytic, 220 μ F, 35 V	ELNA	10×10mm
P1	1	N/A	44-pin edge	N/A	
D1	2	MBRS340T3	Diode, Schottky, 40 V, 3 A	Motorola	SMC
D2		MBRS340T3	Diode, Schottky, 40 V, 3 A	Motorola	SMC
D3	2	SD103–AWDICT	Diode, switching, 200 mA, 40 V	Diodes Inc	DL–35
D4		SD103–AWDICT	Diode, switching, 200 mA, 40 V	Diodes Inc	DL–35
J17	1	PTC36SAAN	Header, 4-pin, 100 mil spacing, (36-pin strip)	Sullins	
J1	1	PTC36SAAN	Header, 14-pin, 100 mil spacing, (36-pin strip)	Sullins	
L1,L2	2	DO3316P–682	Inductor, SMT, 6.8 μ H, 4.4 A,	Coilcraft	
JP1,JP2,JP3	3	PTC36SAAN	Header, 2-pin, 100 mil spacing, (36-pin strip)	Sullins	
R11	1	Std	Resistor, chip, 0 Ω , 1/10 W, 5%	Std	805
R8,R13,R15	3	Std	Resistor, chip, 1 k Ω , 1/10 W, 5%	Std	805
R4	1	Std	Resistor, chip, 1.21 k Ω , 1/10 W, 1%	Std	805
R1,R2	2	Std	Resistor, chip, 5.1 Ω , 1/10 W, 5%	Std	805
R6	1	Std	Resistor, chip, 5.1 k Ω , 1/10 W, 5%	Std	805
R18,R19	2	Std	Resistor, chip, 7.5 k Ω , 1/10 W, 5%	Std	805
R10	2	Std	Resistor, chip, 10 k Ω , 1/10 W, 5%	Std	805
R12		Std	Resistor, chip, 10 k Ω , 1/10 W, 5%	Std	805
R17,R20	2	Std	Resistor, chip, 15 Ω , 1/10 W, 5%	Std	805
R9	1	Std	Resistor, chip, 82 k Ω , 1/10 W, 5%	Std	805
R14	1	Std	Resistor, chip, 310 Ω , 1/10 W, 1%	Std	805
R5	1	Std	Resistor, chip, 680 Ω , 1/10 W, 1%	Std	805
R3,R16,R21	3	Std	OPEN		805
R24	1	Std	Resistor, chip, 1 Ω , 1/8 W, 5%	Std	1206
R26	1	Std	Resistor, chip, 11 Ω , 1/8 W, 5%	Std	1206


Table 3–2. Components on the InfiniBand Bulk Power EVM (SLVP185), Bill of Materials (Continued)

RefDes	Qty	Part Number	Description	MFR	Size
R29	1	Std	Resistor, chip, 75 Ω , 1/8 W, 5%	Std	1206
R22,R25,R30	3	Std	Resistor, chip, 100 Ω , 1/8 W, 5%	Std	1206
R7	1	WSL–2512–01, 1% R86	Resistor, chip, 0.01 Ω , 1 W, 1%	Dale	2512
U2	1	TPS2330ID	Single hot-swap P/controller w/circuit breaker and PG	TI	SO14
U1	1	TPS5102DBT	IC, dual controller, PWM/skip mode	TI	DBT30
TP7,TP29,TP31, TP35	4	240–333	Test point, black, 1 mm	Farnell	
TP1–TP6,TP8–TP28, TP30,TP32, TP33,TP34,TP36	32	240–345	Test point, red, 1 mm	Farnell	
Q1–Q5	5	Si4410DY	MOSFET, N-ch, 30 V, 10–A, 13–m Ω	Siliconix	SO8
Shunts for JP1, JP2	2	929950-00	Jumper shunt	3M	


Layouts of the EVM and the Interface Card

The following figures illustrate the placements of the components and the top-layer layouts for both the InfiniBand bulk power EVM and the interface card respectively. All the components are placed on the top layers only. The bottom layers are ground planes except for a few short traces on the InfiniBand bulk power EVM.

Figure 4–1. Top Layer of the Interface Card and Placement of the Components



Top Layer



Top Assembly

Setup of the EVM


For proper operation of the EVM, one 12-V 1-A power supply, two resistive loads, and a couple of voltage meters are required.

Refer to the setup diagram in Figure 5–1 and follow these steps for hot plug:

- 1) Verify that the power-supply voltage is set at 12 V. Make sure the supply has the capability to provide the current loads need. Turn off the supply.
- 2) Connect the loads to the two output pins—one load connected from VO1 (pin 2 or 3 of J1 on SLVP185) to ground (pin 4 or 5 of J1 on SLVP185), and the other load from VO2 (pin 12 or 13 of J1 on SLVP185) to ground. Monitor the voltages from VO1 and VO2 to ground respectively.
- 3) Plug the supply into the interface card; connect the supply from IN1 to ground. Then turn the power supply on. Check the voltage from VIN1 to GND and it should be about 12 V.
- 4) Slide the switch S1 on the interface board (SLVP155) to HI if the hot-swap controller U2 on SLVP185 is TPS2331 (or to LO if the hot-swap controller U2 on SLVP185 is TPS2330). Otherwise, the supply will not be connected to the loads, because the TPS2331 is an active-high-enabling device and TPS2330 is an active-low-enabling device.
- 5) Short jumpers JP1 and JP3 on the hot-swap board (SLVP185). *Do not* short the jumper JP2.
- 6) Plug the hot-swap board (SLVP185) into the interface board (SLVP155). The key installed between pins 1 and 2 of the edge connector ensures that the board can only be inserted in the correct direction.
- 7) Test points or headers are provided for oscilloscope probes and/or multi-meters. Read the voltage from the multimeters connecting from VO1 (pin 2 or 3 of J1 on SLVP185) and VO2 (pin 12 or 13 of J1 on SLVP185) to GND (pin 4 or 5 of J1 on SLVP185). The values on the meter should be about 5 V and 3.3 V respectively. Otherwise, the board may have problems or the testing may not be correct.
- 8) Unplug the SLVP185 board from the interface card.

The current limits for VO1 and VO2 were set to be less than 3 A on the EVM. If higher currents are required, adjust the resistor values as indicated in the TPS5102 and TPS2331 data sheets, and use a supply with a higher current rating.

Figure 5–1. Evaluation Setup of the InfiniBand Bulk Power EVM



Test Points

Two test points are available on the interface card (SLVP155):

- TP1 – VIN1 (input voltage)
- TP5 – GND (ground)

On the InfiniBand Bulk Power EVM, there are total 36 test points:

- TP1 – Pin 1 (INV1) of TPS5102
- TP2 – Pin 2 (FB1) of TPS5102
- TP3 – Pin 3 (SOFTSTART1) of TPS5102
- TP4 – Pin 4 (PWM/SKIP) of TPS5102
- TP5 – Pin 5 (CT) of TPS5102
- TP6 – Pin 6 (RT) of TPS5102
- TP7 – Pin 7 (GND) of TPS5102
- TP8 – Pin 8 (REF) of TPS5102
- TP9 – Pin 9 (STBY1) of TPS5102
- TP10 – Pin 10 (STBY2) of TPS5102
- TP11 – Pin 11 (VCC) of TPS5102
- TP12 – Pin 12 (COMP) of TPS5102
- TP13 – Pin 13 (SOFTSTART2) of TPS5102
- TP14 – Pin 14 (FB2) of TPS5102
- TP15 – Pin 15 (INV2) of TPS5102
- TP16 – Pin 16 (LH2) of TPS5102
- TP17 – Pin 17 (OUT2U) of TPS5102
- TP18 – Pin 19 (OUT2D) of TPS5102 and gGate of Q4 SI4410DY
- TP19 – Pin 22 (VREF5) of TPS5102
- TP20 – Pin 23 (TRIP2) of TPS5102
- TP21 – Pin 25 (TRIP1) of TPS5102

TP22 – Pin 27 (OUT1D) of TPS5102 and gate of Q2 SI4410DY
TP23 – Pin 29 (OUT1U) of TPS5102
TP24 – Pin 30 (LH1) of TPS5102
TP25 – Gate of Q3 SI4410DY
TP26 – Gate of Q1 SI4410DY
TP27 – Pin1 of J1 (channel 1 control feedback)
TP28 – Pin14 of J1 (channel 2 control feedback)
TP29 – GND
TP30 – Input, pin 1 and 2 of J17
TP31 – GND
TP32 – ENABLE pin of TPS2331
TP33 – PWRGD pin of TPS2331
TP34 – VSENSE pin of TPS2331
TP35 – GND
TP36 – Output of hot-swap stage and input of dc/dc converter

In addition to all the above listed test points, the header J1 on the InfiniBand bulk power EVM can be used as a test point for VO1 and VO2 or connecting loads:

Pins 1 of J1 – same as TP27
Pins 2 and 3 of J1 – VO1
Pins 4 and 5 of J1 – GND
Pins 6 and 7 of J1 – same as TP36
Pins 8 and 9 of J1 – GND
Pins 10 and 11 of J1 – GND
Pins 12 and 13 of J1 – VO2
Pins 14 of J1 – same as TP28