




 **QUANTUM**  
RESEARCH GROUP

# E6248

## User Manual

# E6248

## OVERVIEW

### **Standalone Board Mode**

A 24 key matrix panel is integrated into the E6248 together with LED key indicators. A 14-pin header allows connection to an external matrix panel if required. To operate the board, plug it into a live USB socket.

### **Main User Interface**

This kit is designed for evaluation and development of QT60248 and QT60168-based behind-the-panel touch matrix circuits. It includes all circuitry and materials required to make a fully-functioning, 24-key matrix touch control. This board has a virtual RS232 serial interface via the USB port that allows connection to a PC for function setup and data viewing. The E6248 makes use of QmBtn™ software, which is included.

### **Chip/ Subsidiary Interface**

The QT chip on this board uses SPI for communications. This is directly available on connector J4.

*For more detailed information please refer to the QT60248 datasheet.*

### **Materials Provided:**

- 1x E6248 eval board
- 1x USB cable
- 1x SPI cable for direct connection to the QT60248
- 1x CD-ROM with software and drivers (or get the latest version from [www.qprox.com/toolbox](http://www.qprox.com/toolbox))
- 1x User guide
- 2x QT60248 samples

### **You Will Also Need**

A PC running any recent version of Windows 2000, XP or upwards, with a free USB port.

**Turn to *Software Installation* on page 12 and follow the instructions:**

- Install the QMBtn software as described — *do not run the software yet*
- Connect the E6248 to a free USB port on your PC with the cable provided
- Install the drivers in response to the *Found New Hardware Wizard* — note that this may not be necessary if you have previously installed Quantum hardware on your PC
- Your hardware and software should now be installed correctly

**Double click on the Qmbtn software icon to run the program:**


The software should automatically detect and configure the E6248 device — if not, please refer to the *Troubleshooter* (inside back cover). The main features of the software are described on the following pages.

**Make sure that you explore all of the features of the software, in particular:**

- The **main window** (*Qmbtn*) which provides the ability to monitor the status of all keys and the overall device in real time.
- The **settings window** (*QmSettings*) which allows you to adjust the behaviour of the keys individually to explore the parameter space.
- The **graph window** (*QmGraph*) which allows you to directly monitor the analog outputs of individual keys and effect of the associated settings parameters.

Qmbtn™ is an invaluable tool for developing and testing projects that use Quantum's QMatrix™ technology. The software is designed to communicate with a QMatrix chip via your computer's serial port. It allows you to monitor your chip's status and modify its behaviour.

The **main window** (*QmBtn*) displays device information and the status of each key (Cmd 0x05 and 0x8k).



## APPLICATION MENU

|                  |                              |                                                                                 |
|------------------|------------------------------|---------------------------------------------------------------------------------|
| <b>File ▶</b>    | <b>New</b>                   | Create a new file                                                               |
|                  | <b>Open</b>                  | Open a *.btn file                                                               |
|                  | <b>Save</b>                  | Save the setup of the chip in the current *.btn file                            |
|                  | <b>Save As</b>               | Save the setup of the chip in a new *.btn file                                  |
|                  | <b>Exit</b>                  | Close the software                                                              |
| <b>Options ▶</b> | <b>Beep On Key Down</b>      | Toggle option to generate PC beep on key activation                             |
|                  | <b>Beep On Key Up</b>        | Toggle option to generate PC beep on key release                                |
|                  | <b>Read After Write</b>      | Toggle option to automatically send read command after sending new setup block  |
|                  | <b>Reset After Write</b>     | Toggle option to automatically send reset command after sending new setup block |
|                  | <b>Start/ Stop Data Log</b>  | Toggle feature to record data into a *.csv file                                 |
|                  | <b>QmSettings ▶</b>          | <b>Advanced</b> Display advanced key settings                                   |
|                  | <b>QmGraph ▶</b>             | <b>Join Data Points</b> Draw a solid line in graph                              |
|                  | <b>Save Options On Close</b> | Toggle option to save software settings on close                                |
| <b>View ▶</b>    | <b>Key Settings</b>          | Open the <i>QmSettings</i> window                                               |
|                  | <b>Graph</b>                 | Open the <i>QmGraph</i> window                                                  |
|                  | <b>Key Numbers</b>           | Toggle display of key numbers on keys                                           |
|                  | <b>Key Reference Level</b>   | Toggle display of key reference level on keys                                   |
|                  | <b>Detailed Status</b>       | Toggle display of device and key status                                         |

## SETTINGS WINDOW

The **settings window** (*QmSettings*) allows you to easily visualise and modify the setup of the chip. Clicking the *Read* button in the main window will bring up the current setup of your chip. When a setup option is being modified, its value becomes bold and the *Send* button will become active to indicate that the setup displayed is different from the setup on the chip. Clicking the *Send* button will transfer the new setup block to the chip. The part must be reset for its new settings to become active.

The screenshot shows the **QmSettings** window with a table of key settings. Annotations point to various parts of the interface:

- Click Here to Make Changes to All Keys:** Points to the 'select All' button in the top-left corner.
- Key Number:** Points to the 'Key' column header.
- Press Ctrl + Key to select multiple keys — changes will then apply to all selected keys:** Points to the 'select All' button.
- Setups for Individual Keys:** Points to the 'Key' column header.
- Key Settings (see below):** Points to the 'NTHR', 'NDRIFT', 'NDIL', 'FDIL', 'NRD(s)', 'MAKS', 'Scope', and 'Sync' columns.
- Option Box value becomes bold when changed:** Points to the 'On' value in the 'MAKS' column for Key 9.
- Global Settings (see below):** Points to the 'Global Settings' tab at the bottom.
- Logging (see below):** Points to the 'Logging' tab at the bottom.

| Key    | select All | NTHR | NDRIFT(s) | NDIL | FDIL | NRD(s) | MAKS | Scope | Sync |
|--------|------------|------|-----------|------|------|--------|------|-------|------|
| Key 0  | X0 Y0      | 8    | 2.5       | 2    | 5    | 10.0   | 48   | Off   | Off  |
| Key 1  | X1 Y0      | 10   | 2.5       | 2    | 5    | 10.0   | 32   | Off   | Off  |
| Key 2  | X2 Y0      | 10   | 2.5       | 4    | 5    | 10.0   | 32   | Off   | Off  |
| Key 3  | X3 Y0      | 10   | 2.5       | 2    | 5    | 10.0   | 32   | Off   | Off  |
| Key 4  | X4 Y0      | 10   | 2.5       | 2    | 5    | 10.0   | 32   | Off   | Off  |
| Key 5  | X5 Y0      | 10   | 2.5       | 2    | 5    | 10.0   | 48   | Off   | Off  |
| Key 6  | X6 Y0      | 10   | 2.5       | 2    | 5    | 10.0   | 64   | Off   | Off  |
| Key 7  | X7 Y0      | 10   | 2.5       | 4    | 5    | 10.0   | 48   | Off   | Off  |
| Key 8  | X0 Y1      | 10   | 2.5       | 2    | 5    | 10.0   | 32   | Off   | Off  |
| Key 9  | X1 Y1      | 10   | 2.5       | 4    | 5    | 10.0   | 32   | Off   | Off  |
| Key 10 | X2 Y1      | 10   | 2.5       | 2    | 5    | 10.0   | 32   | Off   | Off  |
| Key 11 | X3 Y1      | 10   | 2.5       | 2    | 5    | 10.0   | 32   | Off   | Off  |
| Key 12 | X4 Y1      | 10   | 2.5       | 2    | 5    | 10.0   | 32   | Off   | Off  |
| Key 13 | X5 Y1      | 10   | 2.5       | 2    | 5    | 10.0   | 48   | Off   | Off  |
| Key 14 | X6 Y1      | 15   | 2.5       | 2    | 5    | 10.0   | 32   | Off   | Off  |
| Key 15 | X7 Y1      | 10   | 2.5       | 2    | 5    | 10.0   | 32   | Off   | Off  |
| Key 16 | X0 Y2      | 8    | 2.5       | 2    | 5    | 10.0   | 48   | Off   | Off  |
| Key 17 | X1 Y2      | 10   | 2.5       | 2    | 5    | 10.0   | 48   | Off   | Off  |
| Key 18 | X2 Y2      | 10   | 2.5       | 2    | 5    | 10.0   | 48   | Off   | Off  |
| Key 19 | X3 Y2      | 10   | 2.5       | 2    | 5    | 10.0   | 48   | Off   | Off  |
| Key 20 | X4 Y2      | 10   | 2.5       | 4    | 5    | 10.0   | 16   | Off   | Off  |
| Key 21 | X5 Y2      | 10   | 2.5       | 2    | 5    | 10.0   | 48   | Off   | Off  |
| Key 22 | X6 Y2      | 10   | 2.5       | 2    | 5    | 10.0   | 64   | Off   | Off  |
| Key 23 | X7 Y2      | 10   | 2.5       | 2    | 5    | 10.0   | 48   | Off   | Off  |

**KEY SETTINGS** (please see your datasheet for a more detailed explanation of key settings)

**NTHR — Negative Threshold** is used to adjust the sensitivity of a key. Higher values make keys less sensitive. Lower values make keys more sensitive.

**NDRIFT — Negative Drift** is the rate at which drift compensation is carried out for a negative going signal (when a key is touched or receives increased loading). The value is in sec/ reference level. For a positive going signal, drift rate is fixed at 0.4 sec. Drift compensation helps to eliminate environmental effects on the chip.

**NDIL — Negative Detection Integrator Limit** allows enabling and disabling of keys and provides signal filtering. Higher values will provide more filtering but increase the response time of the key.

**FDIL — Fast Detection Integrator Limit** also provides filtering, but has less effect on response time. Total filtering is a combination of NDIL and FDIL, for more information on the detection integrator, refer to the datasheet for your chip.

**NRD — Negative Recalibration Delay** determines the maximum time a key can be active before being automatically recalibrated by the chip. The value is in seconds.

**BL — Burst Length** modifies key sensitivity. Higher values make the key more sensitive, lower values have the opposite effect. The correct sensitivity for a key should be achieved with BL and NTHR. As a general rule BL should be as low as possible and NTHR should range from 7 to 12.

**AKS — Adjacent Key Suppression** can be enabled or disabled. To become active, a key with this option enabled must receive the strongest signal relative to other AKS-enabled keys.

**Scope Sync** sends a positive pulse (on Pin 11 S\_SYNC) that brackets the burst of a selected key.

#### GLOBAL SETTINGS *(changes affect all keys)*


**Burst Spacing** — Defines the interval from the start of one burst to the start of the next. Shorter intervals result in faster touch response time; longer intervals allow higher burst lengths and longer conversion times but slower response times.

**Low Signal Limit** — Sets the lowest acceptable value of signal level. If any key's reference level falls below this value, the device declares an error condition in the status bits.

**Mains Sync** — Allows the part to synchronise on the low frequency signal. This is generally used to synchronise acquisition on the mains cycle (50/60Hz). The frequency must be more than 10Hz.

#### LOGGING


These settings have no effect on the chip, they define what data will be recorded when using the Data Logger. The selected readings are recorded in a \*.csv file.



# GRAPH WINDOW

9

The **graph window** (*QmGraph*) displays the analog signal for a selected key. This is a great tool for determining noise level, setting the correct sensitivity and setting the level of filtering required.



**USB Connector (J3)**

This connector provides direct communications between the E6248 and the PC. It allows full control over the device including calibration and setups. It also allows for real-time supervision of signal, reference and calibration information. Uses a standard USB cable (supplied) connected to a PC.

**Matrix Connector (J2)**

The E6248 has a header (J2) to allow connection to an external keyboard. The pinout is described below. The header provides the X-Y scanning of the matrix electrode. X lines drive charge into the matrix, and the Y lines conduct the charge back out. If an external keyboard is used it is a good idea to disconnect the on-board matrix. To do that just cut the links to the matrix (LK1..LK11). Links can be reconnected later by soldering a zero-ohm resistor on the link pads.

| Pin  | 1   | 2  | 3  | 4  | 5  | 6  | 7  | 8  | 9  | 10  | 11 | 12 | 13 | 14  |
|------|-----|----|----|----|----|----|----|----|----|-----|----|----|----|-----|
| Name | GND | X7 | X6 | X5 | X4 | X3 | X2 | X1 | X0 | GND | Y2 | Y1 | Y0 | GND |

**Communication Port Select (OPT1)**

OPT1 allows the user to switch off the USB chip and communicate directly via the SPI port. The SPI signal line can be found on J5. The table below shows the different options. **If the USB chip is on, do not use the SPI line** as it could damage the evaluation board.

**LED Behaviour (OPT2)**

OPT2 allows the user to modify LED behaviour, from On/Off to Toggle. See table below.

| State | ON          | OFF                                      |
|-------|-------------|------------------------------------------|
| OPT1  | USB chip on | USB chip off – all SPI line are floating |
| OPT2  | Latch LED   | Toggle LED                               |

## BOARD DETAILS

11

### SPI Direct Port (J5)

Header J5 gives access to all the signals useful for communicating with the chip. The pinout of the connector is described below:

| Pin  | 1   | 2   | 3     | 4     | 5   | 6    | 7    | 8   | 9         | 10  |
|------|-----|-----|-------|-------|-----|------|------|-----|-----------|-----|
| Name | GND | +5V | +3.3V | /DRDY | /SS | MOSI | MISO | SCK | Line Sync | RST |

### Line Sync (J5, pin 9)

*External Noise Sync:* Feed a TTL or 5V CMOS synchronization pulse into pin 9 of J5 with respect to GND.


Acquisition bursts can be synchronized to an external source of repetitive electrical noise (such as 50Hz or 60Hz) using the Noise Sync feature which can be enabled in QmBtn (View ► Key Settings ► Global Settings). External repetitive signals are thereby heavily suppressed since the system and the noise become synchronized and no longer beat or alias with respect to each other. The sync input triggers the burst for key 0 (X0Y0); the device waits for the sync signal for up to 100 ms after the end of a preceding full matrix scan (after key #23); then, when a sync pulse is received, the matrix is scanned once in its entirety. If no sync pulse is received in 100ms, the part wakes on its own and re-scans the matrix once, then goes back to sleep. Sync pulses should be spaced no more than 99ms apart to prevent this from happening.

### Oscilloscope Sync (SSYNC)

The SSYNC test point can be used to synchronize an oscilloscope. When enabled in QmBtn, this signal provides a pulse that brackets the chosen burst or bursts, making diagnostics much simpler. With the scope sync enabled for one key, the X matrix drive signals can be clearly seen.

### LK12..LK15

These four links provide a simple way to convert 5Volts logic levels to 3.3Volts logic levels. If the host runs at 3.3Volts, these 4 links should be disconnected (using a blade). If the host is running at 5 Volts they should be left connected.



If you have a Quantum CD-ROM, follow these steps to install QmBtn™ software and USB drivers. *If you experience problems, make sure you have administrative rights (under Windows 2000 or XP Pro).*

## Install the QmBtn™ Software

To install the QmBtn software, copy the file *QmBtn[...].exe* from the supplied CD to your PC. The software can be found on the CD in folder **D:\SOFTWARE\** — substitute **D:** with the drive letter of your CD.

For very latest release of QmBtn, check our web site at [www.qprox.com/toolbox](http://www.qprox.com/toolbox)


## Install the USB Drivers

With the supplied CD-ROM in your CD drive, connect the E6248 to your PC with the supplied USB cable.

Windows will display the **Found New Hardware Wizard** for the *PICDEM FS USB*. Select **Install the software automatically** and click **Next**. Windows now installs the drivers. Click **Finish** when prompted.

Windows may prompt you to restart your PC at this point; **restarting is not necessary**.

You are now done with the software and driver installation.



**Board Will  
Not  
Communicate  
with PC****► Bad SPI or USB Connections**

- ⇒ Check/replace cables, LEDs should display on connection
- ⇒ Make sure the board is getting power

**► Bad or Conflicting Virtual Comm Port on PC**

- ⇒ See the *Software Installation* section - reinstall driver software, or, change the USB-Serial com port number in Device Manager if there is a conflict

**► Incorrect Settings on Option Switch**

- ⇒ Set OPT1 to the 'On' position

**Noisy or  
Erratic Signal****► Noisy Power Supply - try a different USB port or PC****► Cables or Board too Close to Strong Noise Source** (such as a power line or switching noise source)


- ⇒ Increase the distance from E6248 to the noise source
- ⇒ Place a grounded metal shield between the noise source and the QMatrix™ board

**► QMatrix™ Board is not Mechanically Stable**

- ⇒ Prevent board from moving around

**► Strong RFI from a Transmitter or Adjacent Digital Product**

- ⇒ Remove the noise source or shield against it



 **QUANTUM**  
RESEARCH GROUP  
[www.qprox.com](http://www.qprox.com)

*Development: Samuel Brunet, Matthew Trend*

**Corporate Headquarters**

1 Mitchell Point  
Ensign Way, Hamble  
Southampton SO31 4RF  
United Kingdom

**Tel** +44 (0)23 8056 5600  
**Fax** +44 (0)23 8045 3939

**Email** [sales1@qprox.com](mailto:sales1@qprox.com)

**North America**

651 Holiday Drive Bldg. 5 / 300  
Pittsburgh, PA 15220  
USA

**Tel** 412-391-7367  
**Fax** 412-291-1015

Copyright © 2005 QRG Ltd  
All rights reserved  
Patented and patents pending  
REV 200.170805