









Atmel

TINY817-QTMOIS2D

A08-S04S Rev 2

PCBA LABEL



UPDI PROG



RESET

CURR MEAS

0V2

2V1 1V8

1V8 1.5V1 3V3

The level translators are used only for different target voltage operations and for digital communication with PC, and are not related to QTouch functionality of the target device



Atmel Corp © 2018

AVR

