



#### ZMS 20

Montageschlüssel für Einbaustecker  
 SFV ... / SGV ... / SGR ...  
 0314 .. / 0315 .. / 0316 .. / 0317 ..  
 und Einbaukupplungen  
 KfV ... / KGV ... / KFR ... / KGR ...  
 0304 .. / 0305 .. / 0306 .. / 0307 ..

#### ZMS 20

Spanner for tightening mounting nuts for male sockets  
 SFV ... / SGV ... / SGR ...  
 0314 .. / 0315 .. / 0316 .. / 0317 ..  
 and female sockets  
 KfV ... / KGV ... / KFR ... / KGR ...  
 0304 .. / 0305 .. / 0306 .. / 0307 ..

#### ZMS 20

Clé de montage pour embases châssis mâles  
 SFV ... / SGV ... / SGR ...  
 0314 .. / 0315 .. / 0316 .. / 0317 ..  
 et embases châssis femelles  
 KfV ... / KGV ... / KFR ... / KGR ...  
 0304 .. / 0305 .. / 0306 .. / 0307 ..



#### 0380

Montageschlüssel für Stecker 0331 .. / 0332 ..  
 und Kupplungen 0321 .. / 0322 ..

#### 0380

Spanner for plugs 0331 .. / 0332 ..  
 and female plugs 0321 .. / 0322 ..

#### 0380

Clé de montage pour fiches mâles 0331 .. / 0332 ..  
 et fiches femelles 0321 .. / 0322 ..


**0383**

Schutzkappe für Stecker  
 SV ... / WSV ... / 0331 ... / 0332 ...  
 und Einbaustecker  
 SFV ... / SGV ... / SGR ... / 0314 ... / 0315 ... / 0316 ... /  
 0317 ...

**0383**

Dust cover for plugs  
 SV ... / WSV ... / 0331 ... / 0332 ...  
 and chassis plugs  
 SFV ... / SGV ... / SGR ... / 0314 ... / 0315 ... / 0316 ... /  
 0317 ...

**0383**

Bouchon de protection pour fiches mâles  
 SV ... / WSV ... / 0331 ... / 0332 ...  
 et pour embases châssis mâles  
 SFV ... / SGV ... / SGR ... / 0314 ... / 0315 ... / 0316 ... /  
 0317 ...


**0381**

Schutzkappe für Kupplungen  
 KV ... / WKV ... / 0321 ... / 0322 ...  
 und Einbaukupplungen  
 KFV ... / KFR ... / KGV ... / KGR ...  
 0304 ... / 0305 ... / 0306 ... / 0307 ...

**0381**

Dust cover for female plugs  
 KV ... / WKV ... / 0321 ... / 0322 ...  
 and female chassis plugs  
 KFV ... / KFR ... / KGV ... / KGR ...  
 0304 ... / 0305 ... / 0306 ... / 0307 ...

**0381**

Bouchon de protection pour fiches femelles  
 KV ... / WKV ... / 0321 ... / 0322 ...  
 et pour embases châssis femelles  
 KFV ... / KFR ... / KGV ... / KGR ...  
 0304 ... / 0305 ... / 0306 ... / 0307 ...


**0382**

Schirmring für Einbaustecker 0314 .. / 0316 ..  
 und Einbaukupplungen 0304 .. / 0306 ..

**0382**

Screening ring for chassis plugs 0314 .. / 0316 ..  
 and female chassis plugs 0304 .. / 0306 ..

**0382**

Bague de blindage pour embases  
 châssis mâles 0314 .. / 0316 ..  
 et pour embases châssis femelles 0304 .. / 0306 ..