

bq27441-G1

Technical Reference



Literature Number: SLUUAC9A
December 2013–Revised May 2015

Preface	4
1 General Description	6
2 Functional Description	8
2.1 Fuel Gauging	8
2.2 Temperature Measurement	8
2.3 Current Measurement	8
2.4 Operating Modes	9
2.4.1 SHUTDOWN Mode	9
2.4	

4.7	RemainingCapacity(): 0x0C and 0x0D	21
4.8	FullChargeCapacity(): 0x0E and 0x0F	22
4.9	AverageCurrent(): 0x10 and 0x11.....	22
4.10	StandbyCurrent(): 0x12 and 0x13.....	22
4.11	MaxLoadCurrent(): 0x14 and 0x15.....	22
4.12	AveragePower(): 0x18	

Preface

This document is a detailed Technical Reference Manual (TRM) for using and configuring the bq27441-G1 battery fuel gauge. This TRM document is intended to complement but not supersede information in the separate bq27441-G1 datasheet.

