




Mounting aid

MH-EXG-18

- Clamp for threaded pipe
- Suitable for all M18 sensors, including reduction factor 1
- Simple and quick exchange without readjustment
- 2 panel nuts included

Quick mounting bracket with dead stop

Dimensions



Technical Data

Mechanical specifications

Length	L	35 mm
Diameter		Sensor adapter 18 mm
Material		brass, nickel-plated
Screwed connection		SW = 30 mm
Dimensions		M24 x 1.5 external thread
Tightening torque		25 Nm

Release date: 2021-06-24 Date of issue: 2021-06-24 Filename: 70112558_eng.pdf

Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

Pepperl+Fuchs Group
www.pepperl-fuchs.com


USA: +1 330 486 0001
fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 1111
fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091
fa-info@sg.pepperl-fuchs.com

PEPPERL+FUCHS

Mounting



Mounting

1. Screw one hexagonal nut (5) onto the thread of sleeve (3).
 2. Push sleeve (3) from the panel back side through an appropriate drill hole in the application.
 3. Screw the second nut (5) from the panel front side onto the thread of sleeve (3).
 4. Use both nuts (5) to adjust the horizontal position of the sensor.
 5. Tighten the nuts (5) with the appropriate torque.
 6. The fixation nut (1) turns on the retaining ring (2). Turn (1) until the three grooves on (1) and (3) are in line.
 7. Insert the sensor from right-hand side through the inner hole of sleeve (3) until it touches the position stop (4).
 8. Turn fixation nut (1) clockwise to fix the sensor. The use of tools is not necessary.
- The sensor is fixed in position.