POWER


NLP250CJ Enclosure

Installation Notes

NLP250CJ
Cover Accessory Kit
NLP250CJ will fit the NLP250 power supplies.

MATERIALS

- One (1) cover
- Four (4) M3x8 mm countersunk screws




Installation Instructions and Notes

1. Place the cover over the NLP250 as shown.
2. Align the cover to the U-bracket countersink holes.
3. Secure four (4) countersink screws provided with in kit as shown.
4. Overall dimensions: 7" (177.8 mm) x 4" (101.6 mm) x 1.6" (40.64 mm).
5. When using this enclosure, ensure that relevant safety standards (e.g., EN60950) are complied with, in respect to creepage and clearance distances, and distances through insulation.
6. All dimensions are in inches (mm)

ARTESYN™
EMBEDDED TECHNOLOGIES

Mechanical Drawing



WORLDWIDE OFFICES

Americas
2900 S.Diablo Way
Tempe, AZ 85282
USA
+1 888 412 7832

Europe (UK)
Waterfront Business Park
Merry Hill, Dudley
West Midlands, DY5 1LX
United Kingdom
+44 (0) 1384 842 211

Asia (HK)
14/F, Lu Plaza
2 Wing Yip Street
Kwun Tong, Kowloon
Hong Kong
+852 2176 3333

ARTESYN™
EMBEDDED TECHNOLOGIES

www.artesyn.com

Artesyn Embedded Technologies, Artesyn and the Artesyn Embedded Technologies logo are trademarks and service marks of Artesyn Embedded Technologies, Inc. All other names and logos referred to are trade names, trademarks, or registered trademarks of their respective owners. Specifications are subject to change without notice. © 2017 Artesyn Embedded Technologies, Inc. All rights reserved. For full legal terms and conditions, please visit www.artesyn.com/legal.

For more information: www.artesyn.com/power
For support: productsupport.ep@artesyn.com