

\*J1 and J2 are the BNC connectors to coaxial cable for noise measurement, please refer to AN70 Appendix B for details.

