

TPS563900EVM-574, 3.5-A, SWIFT™ Regulator Evaluation Module

This user's guide contains information for the TPS563900EVM-574 evaluation module (PWR574) as well as for the TPS563900 dc/dc converter. Also included are the performance specifications, the schematic, and the bill of materials for the TPS563900EVM-574.

Contents

1	Introduction	3
2	Test Setup and Results	5
3	Board Layout.....	20
4	Schematic and Bill of Materials.....	22

List of Figures

1	TPS563900 GUI_ver_0_0_0_2 Screen	4
2	TPS563900EVM-574 V_{OUT1} CCM Efficiency	7
3	TPS563900EVM-574 V_{OUT2} CCM Efficiency	7
4	TPS563900EVM-574 V_{OUT1} CCM Low Current Efficiency	8
5	TPS563900EVM-574 V_{OUT2} CCM Low Current Efficiency	8
6	TPS563900EVM-574 V_{OUT1} SKIP Mode Efficiency	9
7	TPS563900EVM-574 V_{OUT2} SKIP Mode Efficiency	9
8	TPS563900EVM-574 V_{OUT1} SKIP Mode Low Current Efficiency	10
9	TPS563900EVM-574 V_{OUT2} SKIP Mode Low Current Efficiency	10
10	TPS563900EVM-574 V_{OUT1} CCM Load Regulation	11
11	TPS563900EVM-574 V_{OUT2} CCM Load Regulation	11
12	TPS563900EVM-574 V_{OUT1} SKIP Mode Load Regulation.....	12
13	TPS563900EVM-574 V_{OUT2} SKIP Mode Load Regulation.....	12
14	TPS563900EVM-574 V_{OUT1} CCM Line Regulation	13
15	TPS563900EVM-574 V_{OUT2} CCM Line Regulation	13
16	TPS563900EVM-574 V_{OUT1} SKIP Mode Line Regulation.....	14
17	TPS563900EVM-574 V_{OUT2} SKIP Mode Line Regulation.....	14
18	TPS563900EVM-574 V_{OUT1} Transient Response.....	15
19	TPS563900EVM-574 V_{OUT2} Transient Response.....	15
20	TPS563900EVM-574 Loop Response, V_{OUT1} Set by Resistor Divider.....	16
21	TPS563900EVM-574 Loop Response, V_{OUT2} Set by Resistor Divider.....	16
22	TPS563900EVM-574 Output Ripple for Light Loads in SKIP Mode.....	17
23	TPS563900EVM-574 Output Ripple for No Load in CCM	17
24	TPS563900EVM-574 Output Ripple for Full Load CCM	18
25	TPS563900EVM-574 Start Up.....	19
26	TPS563900EVM-574 Shut Down	19
27	TPS563900EVM-574 Top-Side Assembly	20
28	TPS563900EVM-574 Top-Side Layout.....	20
29	TPS563900EVM-574 Internal Layer-1 Layout.....	21

SWIFT is a trademark of Texas Instruments.

30	TPS563900EVM-574 Internal Layer-2 Layout.....	21
31	TPS563900EVM-574 Bottom-Side Layout.....	21
32	TPS563900EVM-574 Schematic.....	22

List of Tables

1	Input Voltage and Output Current Summary.....	3
2	TPS563900EVM-574 Performance Specification Summary.....	3
3	EVM Connectors and Test Points.....	6
4	TPS563900EVM-574 Bill of Materials.....	23

1 Introduction

1.1 Background

The TPS563900 is a dual output current mode control dc/dc converter with output rated for up to 3.5 A. The input voltage range is 4.5 V to 18 V. Rated input voltage and output current range for the evaluation module are given in [Table 1](#). The TPS563900 features I²C VID control. The output voltage for each channel can be set within the range of 0.68 V to 1.95 V. This evaluation module is designed to demonstrate the small printed-circuit-board (PCB) areas that may be achieved when designing with the TPS563900 regulator. The switching frequency is externally set at a nominal 500 kHz. The high-side and low-side MOSFETs are incorporated inside the TPS563900 package along with the gate drive circuitry. The low drain-to-source on-resistance of the MOSFET allows the TPS563900 to achieve high efficiencies and helps keep the junction temperature low at high output currents. The compensation components are external to the integrated circuit (IC), and an external divider allows for an adjustable output voltage. Additionally, the TPS563900 provides adjustable slow start and undervoltage lockout inputs. The absolute maximum input voltage is 20 V for the TPS563900EVM-574.

Table 1. Input Voltage and Output Current Summary

EVM	Input Voltage Range	Output Current Range
TPS563900EVM-574	V _{IN} = 4.5 V to 18 V	V _{OUT1} = V _{OUT2} = 0 A to 3.5 A

1.2 Performance Specification Summary

A summary of the TPS563900EVM-574 performance specifications is provided in [Table 2](#). Specifications are given for an input voltage of V_{IN} = 12 V and an output voltage of 1.0 V for V_{OUT1} and 1.1 V for V_{OUT2}, unless otherwise specified. The TPS563900EVM-574 is designed and tested for V_{IN} = 4.5 V to 18 V with the VIN and PVIN pins connect together. The ambient temperature is 25°C for all measurements, unless otherwise noted.

Table 2. TPS563900EVM-574 Performance Specification Summary

Specification	Test Conditions	MIN	TYP	MAX	Unit
V _{IN} voltage range (PVIN = VIN)		4.5	12	18	V
V _{IN} start voltage (internal UVLO)			2.12		V
V _{IN} stop voltage (internal UVLO)			1.74		V
Output voltage set point, V _{OUT1}			1.0		V
Output current range, V _{OUT1}	V _{IN} = 4.5 V to 18 V	0		3.5	A
Output voltage set point, V _{OUT2}			1.1		
Output current range, V _{OUT2}	V _{IN} = 4.5 V to 18 V	0		3.5	
Line regulation, V _{OUT1} and V _{OUT2}	I _O = 1.75 A, V _{IN} = 4.5 V to 18 V		±0.02		%
Load regulation, V _{OUT1} and V _{OUT2}	V _{IN} = 5 V, I _O = 0 A to 3.5 A		±0.35		%
Load transient response, V _{OUT1} and V _{OUT2}	I _O = 0.5 A to 2.5 A	Voltage change		-40	mV
		Recovery time		100	µs
	I _O = 2.5 A to 0.5 A	Voltage change		40	mV
		Recovery time		100	µs
Output ripple voltage, V _{OUT1} and V _{OUT2}	I _O = 3.5 A		10		mVPP
Output rise time, V _{OUT1} and V _{OUT2}			1		ms
Operating frequency			500		kHz

1.3 Modifications

These evaluation modules are designed to provide access to the features of the TPS563900. Some modifications can be made to this module.

1.3.1 Output Voltage Setpoint

The output voltage of the EVM is set either externally using a voltage divider or internally using the integrated I²C interface. The external adjustment of the output voltage for V_{OUT1} is set by the resistor divider network of R10 and R11. The external adjustment of the output voltage for V_{OUT2} is set by the resistor divider network of R16 and R17. R10 and R16 are fixed at 40.2 kΩ. To change the output voltage of V_{OUT1} or V_{OUT2}, it is necessary to change the value of resistor R11 or R17. Changing the value of R11 or R17 can change the output voltage in the range of 0.68 V to 1.95 V. The value of R11 or R17 for a specific output voltage can be calculated using [Equation 1](#) or [Equation 2](#).

$$R11 = \frac{R10 \times 0.6V}{V_{OUT} - 0.6V} \quad (1)$$

or

$$R17 = \frac{R16 \times 0.6V}{V_{OUT} - 0.6V} \quad (2)$$

The output voltage can also be set using the optional VID control using the I²C interface. The EVM is designed so that the J2 connector is compatible with the HPA172 USB Interface Adapter. Using that control and TPS563900 GUI_ver_0_0_0_2 software allows the output voltage to be programmed to any of 128 preset voltages from 0.68 V to 1.95 V. JP2-2 and JP2-3 should be covered to select the default address. JP3 should be open to allow the I²C pull up to be supplied from the USB adapter, available from www.ti.com/tool/usb-to-gpio. The USB adapter is also available from the [TI eStore](#). See the TPS563900 datasheet ([SLVSCC7](#)) for a complete description of the available codes. With the software running and the cable attached, run the GUI interface software ([SLVC558](#)). [Figure 1](#) shows the GUI interface.




Figure 1. TPS563900 GUI_ver_0_0_0_2 Screen

To change the output voltages, ensure that the VID Enable check boxes are checked. The voltages can be interactively changed using the slide controls when "Write On Change: ON" is active. See the TPS563900 datasheet for further details.

1.3.2 Slow-Start Time

The slow-start time can be adjusted by changing the value of C7 or C8 for V_{OUT1} or V_{OUT2} . Use [Equation 3](#) or [Equation 4](#) to calculate the required value of C7 or C8 for desired slow-start times.

$$C7(\text{nF}) = \frac{T_{\text{ss}}(\text{ms}) \times 6 \mu\text{A}}{0.6 \text{ V}} \quad (3)$$

or

$$C8(\text{nF}) = \frac{T_{\text{ss}}(\text{ms}) \times 6 \mu\text{A}}{0.6 \text{ V}} \quad (4)$$

The EVM is set for a slow-start time of 1 ms using $C7 = C8 = 10 \text{ nF}$.

1.3.3 Adjustable UVLO

The undervoltage lockout (UVLO) can be adjusted externally using R3 and R4 or R5 and R6 for V_{OUT1} or V_{OUT2} . Use [Equation 5](#) and [Equation 6](#) to calculate required resistor values for different start voltages.

$$R3 = \frac{V_{\text{START}} \left(\frac{V_{\text{ENFALLING}}}{V_{\text{ENRISING}}} \right) - V_{\text{STOP}}}{I_p \left(1 - \frac{V_{\text{ENFALLING}}}{V_{\text{ENRISING}}} \right) + I_h} \quad (5)$$

or

$$R5 = \frac{V_{\text{START}} \left(\frac{V_{\text{ENFALLING}}}{V_{\text{ENRISING}}} \right) - V_{\text{STOP}}}{I_p \left(1 - \frac{V_{\text{ENFALLING}}}{V_{\text{ENRISING}}} \right) + I_h} \quad (6)$$

Use [Equation 7](#) or [Equation 8](#) to calculate required resistor values for different stop voltages.

$$R4 = \frac{R3 \times V_{\text{ENFALLING}}}{V_{\text{STOP}} - V_{\text{ENFALLING}} + R3(I_p + I_h)} \quad (7)$$

or

$$R6 = \frac{R5 \times V_{\text{ENFALLING}}}{V_{\text{STOP}} - V_{\text{ENFALLING}} + R5(I_p + I_h)} \quad (8)$$

2 Test Setup and Results

This section describes how to properly connect, set up, and use the TPS563900EVM-574 evaluation module. The section also includes test results typical for the evaluation module and covers efficiency, output voltage regulation, load transients, loop response, output ripple, input ripple, and start-up.

2.1 Input/Output Connections

The TPS563900EVM-574 is provided with input/output connectors and test points as shown in [Table 3](#). A power supply capable of supplying 5 A must be connected to J1 through a pair of 20-AWG wires. The loads must be connected to J3 and J4 through a pair of 20-AWG wires. The maximum load current capability is 3.5 A for each output. Wire lengths must be minimized to reduce losses in the wires. Test-point TP1 provides a place to monitor the V_{IN} input voltages with TP2 providing a convenient ground reference. TP11 is used to monitor V_{OUT1} with TP12 as the ground reference. TP15 is used to monitor V_{OUT2} with TP15 as the ground reference.

Table 3. EVM Connectors and Test Points

Reference Designator	Function
J1	VIN input voltage connector. (See Table 1 for V_{IN} range.)
J2	I ² C interface connector.
J3	V_{OUT1} , 1.0 V at 3.5 A maximum
J4	V_{OUT2} , 1.1 V at 3.5 A maximum
JP1	MODE select. Cover JP1-2 and JP1-3 to select forced CCM mode. Leave open to select PSM pulse skipping mode for increased light-load efficiency
JP2	ADDR select. Normally cover JP2-2 and JP2-3.
JP3	Jumper to select internal LDO as I ² C pull up voltage. Normally open to allow pull up voltage from the USB interface adapter.
JP4	2-pin header for V_{OUT1} enable. Connect EN to ground to disable, open to enable.
JP5	2-pin header for V_{OUT2} enable. Connect EN to ground to disable, open to enable.
TP1	VIN test point at VIN connector.
TP2	GND test point at VIN connector.
TP3	LDO output test point.
TP4	External I ² C pull up voltage test point.
TP5	V_{OUT1} enable test point.
TP6	V_{OUT2} enable test point.
TP7	V_{OUT1} slow start test point.
TP8	V_{OUT2} slow start test point.
TP9	V_{OUT1} LX1 switching node test point.
TP10	Test point in V_{OUT1} voltage divider network. Used for loop response measurements when output voltage is set using external resistor divider network.
TP11	Output voltage test point at V_{OUT1} connector.
TP12	GND test point at V_{OUT1} connector.
TP13	V_{OUT2} LX2 switching node test point.
TP14	Test point in V_{OUT2} voltage divider network. Used for loop response measurements when output voltage is set using external resistor divider network.
TP15	Output voltage test point at V_{OUT2} connector.
TP16	GND test point at V_{OUT2} connector.
TP17	Analog GND test point.
TP18	I ² C SDA test point.
TP19	I ² C SCL test point.

2.2 Efficiency

Figure 2 and Figure 3 show the efficiency for the TPS563900EVM-574 in CCM at an ambient temperature of 25°C.




Figure 2. TPS563900EVM-574 V_{OUT1} CCM Efficiency




Figure 3. TPS563900EVM-574 V_{OUT2} CCM Efficiency

Figure 4 and Figure 5 show the efficiency for the TPS563900EVM-574 in CCM using a semi-log scale to more easily show efficiency at lower output currents. The ambient temperature is 25°C.




Figure 4. TPS563900EVM-574 V_{OUT1} CCM Low Current Efficiency




Figure 5. TPS563900EVM-574 V_{OUT2} CCM Low Current Efficiency

Figure 6 and Figure 7 show the efficiency for the TPS563900EVM-574 in SKIP mode at an ambient temperature of 25°C.




Figure 6. TPS563900EVM-574 V_{OUT1} SKIP Mode Efficiency




Figure 7. TPS563900EVM-574 V_{OUT2} SKIP Mode Efficiency

Figure 8 and Figure 9 show the efficiency for the TPS563900EVM-574 in SKIP mode using a semi-log scale to more easily show efficiency at lower output currents. The ambient temperature is 25°C.




Figure 8. TPS563900EVM-574 V_{OUT1} SKIP Mode Low Current Efficiency




Figure 9. TPS563900EVM-574 V_{OUT2} SKIP Mode Low Current Efficiency

The efficiency may be lower at higher ambient temperatures, due to temperature variation in the drain-to-source resistance of the internal MOSFET.

2.3 Output Voltage Load Regulation

Figure 10 and Figure 11 show the load regulation for the TPS563900EVM-574 in CCM.




Figure 10. TPS563900EVM-574 V_{OUT1} CCM Load Regulation




Figure 11. TPS563900EVM-574 V_{OUT2} CCM Load Regulation

Figure 12 and Figure 13 show the load regulation for the TPS563900EVM-574 in SKIP mode.




Figure 12. TPS563900EVM-574 V_{OUT1} SKIP Mode Load Regulation




Figure 13. TPS563900EVM-574 V_{OUT2} SKIP Mode Load Regulation

Measurements are given for an ambient temperature of 25°C.

2.4 Output Voltage Line Regulation

Figure 14 and Figure 15 show the line regulation for the TPS563900EVM-574 in CCM.




Figure 14. TPS563900EVM-574 V_{OUT1} CCM Line Regulation




Figure 15. TPS563900EVM-574 V_{OUT2} CCM Line Regulation

Figure 16 and Figure 17 show the line regulation for the TPS563900EVM-574 in SKIP mode.




Figure 16. TPS563900EVM-574 V_{OUT1} SKIP Mode Line Regulation




Figure 17. TPS563900EVM-574 V_{OUT2} SKIP Mode Line Regulation

2.5 Load Transients

Figure 18 and Figure 19 show the TPS563900EVM-574 response to load transients. Total peak-to-peak voltage variation is as shown, including ripple and noise on the output.




Figure 18. TPS563900EVM-574 V_{OUT1} Transient Response




Figure 19. TPS563900EVM-574 V_{OUT2} Transient Response

2.6 Loop Characteristics

Figure 20 and Figure 21 show the TPS563900EVM-574 loop-response characteristics when the output voltage is set by the external resistor divider network. Gain and phase plots are shown for V_{IN} voltage of 12 V. Load current for the measurement is 1.75 A.




Figure 20. TPS563900EVM-574 Loop Response, V_{OUT1} Set by Resistor Divider




Figure 21. TPS563900EVM-574 Loop Response, V_{OUT2} Set by Resistor Divider

2.7 Output Voltage Ripple

Figure 22, Figure 23, and Figure 24 show the TPS563900EVM-574 output voltage ripple. The output currents are as shown in the figures. $V_{IN} = 12\text{ V}$. The ripple voltage is measured directly across the output capacitors.




Figure 22. TPS563900EVM-574 Output Ripple for Light Loads in SKIP Mode




Figure 23. TPS563900EVM-574 Output Ripple for No Load in CCM




Figure 24. TPS563900EVM-574 Output Ripple for Full Load CCM

2.8 Powering Up

Figure 25 shows the start-up waveforms for the TPS563900EVM-574 relative to EN1. EN2 is not shown, but the timing is the same relative to V_{IN} and EN1. The input voltage for these plots is 12 V and the load is 1 Ω .




Figure 25. TPS563900EVM-574 Start Up

2.9 Shutting Down

Figure 26 shows the shut down waveforms for the TPS563900EVM-574 relative to EN1. EN2 is not shown, but the timing is the same relative to V_{IN} and EN1. The input voltage for these plots is 12 V and the load is 1 Ω .




Figure 26. TPS563900EVM-574 Shut Down

3 Board Layout

This section provides a description of the TPS563900EVM-574 board layout and layer illustrations.

3.1 Layout

The board layout for the TPS563900EVM-574 is shown in [Figure 27](#) through [Figure 31](#). The top-side layer of the EVM is laid out in a manner typical of a user application. The top, bottom, and internal layers are 2-oz. copper.

The top layer contains the main power traces for V_{IN} , V_{OUT1} , V_{OUT2} and switching nodes. Also on the top layer are connections for the remaining pins of the TPS563900 and a large area filled with ground. The internal layer-1 is dedicated to a power ground plane. The internal layer-2 contains additional V_{IN} , V_{OUT1} and V_{OUT2} copper fill areas as well as signal routing traces. The bottom layer contains a power ground plane only. The top-side ground traces are connected to the bottom and internal ground planes with multiple vias placed around the board.

The input decoupling capacitors (C1 and C2) and 7V LDO output capacitor C3 and bootstrap capacitors (C9 and C19) are all located as close to the IC as possible. Additionally, the voltage set point resistor divider components are kept close to the IC. The voltage divider network ties to the output voltages at the point of regulation, the copper V_{OUT1} and V_{OUT2} traces on the internal layer-2 near the J3 and J4 output connectors respectively. For the TPS563900, an additional input bulk capacitor may be required, depending on the EVM connection to the input supply.




Figure 27. TPS563900EVM-574 Top-Side Assembly




Figure 28. TPS563900EVM-574 Top-Side Layout




Figure 29. TPS563900EVM-574 Internal Layer-1 Layout




Figure 30. TPS563900EVM-574 Internal Layer-2 Layout




Figure 31. TPS563900EVM-574 Bottom-Side Layout

4 Schematic and Bill of Materials

This section presents the TPS563900EVM-574 schematic and bill of materials.

4.1 Schematic

Figure 32 is the schematic for the TPS563900EVM-574.




Figure 32. TPS563900EVM-574 Schematic

4.2 Bill of Materials

Table 4 presents the bill of materials for the TPS563900EVM-574.

Table 4. TPS563900EVM-574 Bill of Materials

Designator	Qty	Value	Description	Package Reference	Part Number	Manufacturer
C1, C2	2	10uF	CAP, CERM, 10uF, 25V, +/-10%, X5R, 1206	1206	GRM31CR61E106KA12L	MuRata
C3	1	10uF	CAP, CERM, 10uF, 10V, +/-10%, C0G/NP0, 0603	0603	C1608X5R1A106M	TDK
C4	1	1uF	CAP, CERM, 1uF, 25V, +/-10%, X5R, 0603	0603	GRM188R61E105KA12D	MuRata
C5, C6, C7, C8, C11, C21	6	0.01uF	CAP, CERM, 0.01uF, 50V, +/-10%, X7R, 0603	0603	GRM188R71H103KA01D	MuRata
C9, C19	2	0.47uF	CAP, CERM, 0.47uF, 25V, +/-10%, X5R, 0603	0603	GRM188R61E474KA12D	MuRata
C10, C20	2	47pF	CAP, CERM, 47pF, 50V, +/-5%, C0G/NP0, 0603	0603	GRM1885C1H470JA01D	MuRata
C12, C13, C14, C15, C16, C17, C22, C23, C24, C25, C26, C27	12	22uF	CAP, CERM, 22uF, 10V, +/-10%, X5R, 1206	1206	GRM31CR61A226KE19L	MuRata
C18, C28	2	82pF	CAP, CERM, 82pF, 50V, +/-5%, C0G/NP0, 0603	0603	GRM1885C1H820JA01D	MuRata
H1, H2, H3, H4	4		Machine Screw, Round, 4-40 x 1/4, Nylon, Phillips panhead	Screw	NY PMS 440 0025 PH	B&F Fastener Supply
H5, H6, H7, H8	4		Standoff, Hex, 0.5"L 4-40 Nylon	Standoff	1902C	Keystone
J1, J3, J4	3		Terminal Block, 6A, 3.5mm Pitch, 2-Pos, TH	7.0x8.2x6.5mm	ED555/2DS	On-Shore Technology
J2	1		Header (shrouded), 100mil, 5x2, High-Temperature, Gold, TH	5x2 Shrouded header	N2510-6002-RB	3M
JP1, JP2	2		Header, TH, 100mil, 3x1, Gold plated, 230 mil above insulator	3x1 Header	TSW-103-07-G-S	Samtec
JP3, JP4, JP5	3		Header, TH, 100mil, 2x1, Gold plated, 230 mil above insulator	2x1 Header	TSW-102-07-G-S	Samtec
L1, L2	2	2.2uH	Inductor, Shielded Drum Core, Superflux, 2.2uH, 9A, 0.0115 ohm, SMD	WE-HC4	744311220	Würth Elektronik eiSos
LBL1	1		Thermal Transfer Printable Labels, 1.250" W x 0.250" H - 10,000 per roll	PCB Label 1.25"H x 0.250"W	THT-13-457-10	Brady
R1, R2	2	10.0k	RES, 10.0k ohm, 1%, 0.1W, 0603	0603	CRCW060310K0FKEA	Vishay-Dale
R3, R4, R5, R6	4	100k	RES, 100k ohm, 1%, 0.1W, 0603	0603	CRCW0603100KFKFA	Vishay-Dale
R7, R9, R12, R15	4	0	RES, 0 ohm, 5%, 0.1W, 0603	0603	CRCW0603000Z0EA	Vishay-Dale
R8, R13	2	2.74k	RES, 2.74k ohm, 1%, 0.1W, 0603	0603	CRCW06032K74FKFA	Vishay-Dale
R10, R16	2	40.2k	RES, 40.2k ohm, 1%, 0.1W, 0603	0603	CRCW060340K2FKFA	Vishay-Dale
R11	1	48.7k	RES, 48.7k ohm, 1%, 0.1W, 0603	0603	CRCW060348K7FKFA	Vishay-Dale
R14	1	80.6k	RES, 80.6k ohm, 1%, 0.1W, 0603	0603	CRCW060380K6FKFA	Vishay-Dale
R17	1	60.4k	RES, 60.4k ohm, 1%, 0.1W, 0603	0603	CRCW060360K4FKFA	Vishay-Dale
SH-JP1, SH-JP2, SH-JP3, SH-JP4, SH-JP5	5	1x2	Shunt, 2mm, Gold plated, Black	2mm Shunt, Closed Top	2SN-BK-G	Samtec
TP1, TP3, TP4, TP11, TP15	5	Red	Test Point, Miniature, Red, TH	Red Miniature Testpoint	5000	Keystone
TP2, TP12, TP16, TP17	4	Black	Test Point, Miniature, Black, TH	Black Miniature Testpoint	5001	Keystone
TP5, TP6, TP7, TP8, TP10, TP14, TP18, TP19	8	White	Test Point, Miniature, White, TH	White Miniature Testpoint	5002	Keystone
TP9, TP13	2	Yellow	Test Point, Miniature, Yellow, TH	Yellow Miniature Testpoint	5004	Keystone
U1	1		4.5V to 18V Input, 3A/3A Dual Synchronous Step-Down SWIFT Converter With I2C Controlled VID, DAP0032A	DAP0032A	TPS563900DAP	Texas Instruments
FID1, FID2, FID3	0		Fiducial mark. There is nothing to buy or mount.	Fiducial	N/A	N/A

4.3 Reference

1. *TPS563900 4.5-V to 18-V Input, 3.5-A/3.5-A Dual Synchronous Step-Down Converter With I²C Controlled VID* data sheet ([SLVSCC7](#))

ADDITIONAL TERMS AND CONDITIONS, WARNINGS, RESTRICTIONS, AND DISCLAIMERS FOR EVALUATION MODULES

Texas Instruments Incorporated (TI) markets, sells, and loans all evaluation boards, kits, and/or modules (EVMs) pursuant to, and user expressly acknowledges, represents, and agrees, and takes sole responsibility and risk with respect to, the following:

1. User agrees and acknowledges that EVMs are intended to be handled and used for feasibility evaluation only in laboratory and/or development environments. Notwithstanding the foregoing, in certain instances, TI makes certain EVMs available to users that do not handle and use EVMs solely for feasibility evaluation only in laboratory and/or development environments, but may use EVMs in a hobbyist environment. All EVMs made available to hobbyist users are FCC certified, as applicable. Hobbyist users acknowledge, agree, and shall comply with all applicable terms, conditions, warnings, and restrictions in this document and are subject to the disclaimer and indemnity provisions included in this document.
2. Unless otherwise indicated, EVMs are not finished products and not intended for consumer use. EVMs are intended solely for use by technically qualified electronics experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, systems, and subsystems.
3. User agrees that EVMs shall not be used as, or incorporated into, all or any part of a finished product.
4. User agrees and acknowledges that certain EVMs may not be designed or manufactured by TI.
5. User must read the user's guide and all other documentation accompanying EVMs, including without limitation any warning or restriction notices, prior to handling and/or using EVMs. Such notices contain important safety information related to, for example, temperatures and voltages. For additional information on TI's environmental and/or safety programs, please visit www.ti.com/esh or contact TI.
6. User assumes all responsibility, obligation, and any corresponding liability for proper and safe handling and use of EVMs.
7. Should any EVM not meet the specifications indicated in the user's guide or other documentation accompanying such EVM, the EVM may be returned to TI within 30 days from the date of delivery for a full refund. THE FOREGOING LIMITED WARRANTY IS THE EXCLUSIVE WARRANTY MADE BY TI TO USER AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. TI SHALL NOT BE LIABLE TO USER FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RELATED TO THE HANDLING OR USE OF ANY EVM.
8. No license is granted under any patent right or other intellectual property right of TI covering or relating to any machine, process, or combination in which EVMs might be or are used. TI currently deals with a variety of customers, and therefore TI's arrangement with the user is not exclusive. TI assumes no liability for applications assistance, customer product design, software performance, or infringement of patents or services with respect to the handling or use of EVMs.
9. User assumes sole responsibility to determine whether EVMs may be subject to any applicable federal, state, or local laws and regulatory requirements (including but not limited to U.S. Food and Drug Administration regulations, if applicable) related to its handling and use of EVMs and, if applicable, compliance in all respects with such laws and regulations.
10. User has sole responsibility to ensure the safety of any activities to be conducted by it and its employees, affiliates, contractors or designees, with respect to handling and using EVMs. Further, user is responsible to ensure that any interfaces (electronic and/or mechanical) between EVMs and any human body are designed with suitable isolation and means to safely limit accessible leakage currents to minimize the risk of electrical shock hazard.
11. User shall employ reasonable safeguards to ensure that user's use of EVMs will not result in any property damage, injury or death, even if EVMs should fail to perform as described or expected.
12. User shall be solely responsible for proper disposal and recycling of EVMs consistent with all applicable federal, state, and local requirements.

Certain Instructions. User shall operate EVMs within TI's recommended specifications and environmental considerations per the user's guide, accompanying documentation, and any other applicable requirements. Exceeding the specified ratings (including but not limited to input and output voltage, current, power, and environmental ranges) for EVMs may cause property damage, personal injury or death. If there are questions concerning these ratings, user should contact a TI field representative prior to connecting interface electronics including input power and intended loads. Any loads applied outside of the specified output range may result in unintended and/or inaccurate operation and/or possible permanent damage to the EVM and/or interface electronics. Please consult the applicable EVM user's guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative. During normal operation, some circuit components may have case temperatures greater than 60°C as long as the input and output are maintained at a normal ambient operating temperature. These components include but are not limited to linear regulators, switching transistors, pass transistors, and current sense resistors which can be identified using EVMs' schematics located in the applicable EVM user's guide. When placing measurement probes near EVMs during normal operation, please be aware that EVMs may become very warm. As with all electronic evaluation tools, only qualified personnel knowledgeable in electronic measurement and diagnostics normally found in development environments should use EVMs.

Agreement to Defend, Indemnify and Hold Harmless. User agrees to defend, indemnify, and hold TI, its directors, officers, employees, agents, representatives, affiliates, licensors and their representatives harmless from and against any and all claims, damages, losses, expenses, costs and liabilities (collectively, "Claims") arising out of, or in connection with, any handling and/or use of EVMs. User's indemnity shall apply whether Claims arise under law of tort or contract or any other legal theory, and even if EVMs fail to perform as described or expected.

Safety-Critical or Life-Critical Applications. If user intends to use EVMs in evaluations of safety critical applications (such as life support), and a failure of a TI product considered for purchase by user for use in user's product would reasonably be expected to cause severe personal injury or death such as devices which are classified as FDA Class III or similar classification, then user must specifically notify TI of such intent and enter into a separate Assurance and Indemnity Agreement.

RADIO FREQUENCY REGULATORY COMPLIANCE INFORMATION FOR EVALUATION MODULES

Texas Instruments Incorporated (TI) evaluation boards, kits, and/or modules (EVMs) and/or accompanying hardware that is marketed, sold, or loaned to users may or may not be subject to radio frequency regulations in specific countries.

General Statement for EVMs Not Including a Radio

For EVMs not including a radio and not subject to the U.S. Federal Communications Commission (FCC) or Industry Canada (IC) regulations, TI intends EVMs to be used only for engineering development, demonstration, or evaluation purposes. EVMs are not finished products typically fit for general consumer use. EVMs may nonetheless generate, use, or radiate radio frequency energy, but have not been tested for compliance with the limits of computing devices pursuant to part 15 of FCC or the ICES-003 rules. Operation of such EVMs may cause interference with radio communications, in which case the user at his own expense will be required to take whatever measures may be required to correct this interference.

General Statement for EVMs including a radio

User Power/Frequency Use Obligations: For EVMs including a radio, the radio included in such EVMs is intended for development and/or professional use only in legally allocated frequency and power limits. Any use of radio frequencies and/or power availability in such EVMs and their development application(s) must comply with local laws governing radio spectrum allocation and power limits for such EVMs. It is the user's sole responsibility to only operate this radio in legally acceptable frequency space and within legally mandated power limitations. Any exceptions to this are strictly prohibited and unauthorized by TI unless user has obtained appropriate experimental and/or development licenses from local regulatory authorities, which is the sole responsibility of the user, including its acceptable authorization.

U.S. Federal Communications Commission Compliance

For EVMs Annotated as FCC – FEDERAL COMMUNICATIONS COMMISSION Part 15 Compliant

Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications could void the user's authority to operate the equipment.

FCC Interference Statement for Class A EVM devices

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at its own expense.

FCC Interference Statement for Class B EVM devices

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Industry Canada Compliance (English)

For EVMs Annotated as IC – INDUSTRY CANADA Compliant:

This Class A or B digital apparatus complies with Canadian ICES-003.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Concerning EVMs Including Radio Transmitters

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Concerning EVMs Including Detachable Antennas

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

This radio transmitter has been approved by Industry Canada to operate with the antenna types listed in the user guide with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Canada Industry Canada Compliance (French)

Cet appareil numérique de la classe A ou B est conforme à la norme NMB-003 du Canada

Les changements ou les modifications pas expressément approuvés par la partie responsable de la conformité ont pu vider l'autorité de l'utilisateur pour actionner l'équipement.

Concernant les EVMs avec appareils radio

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Concernant les EVMs avec antennes détachables

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

Le présent émetteur radio a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés dans le manuel d'usage et ayant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2014, Texas Instruments Incorporated

Important Notice for Users of EVMs Considered “Radio Frequency Products” in Japan

EVMs entering Japan are NOT certified by TI as conforming to Technical Regulations of Radio Law of Japan.

If user uses EVMs in Japan, user is required by Radio Law of Japan to follow the instructions below with respect to EVMs:

1. Use EVMs in a shielded room or any other test facility as defined in the notification #173 issued by Ministry of Internal Affairs and Communications on March 28, 2006, based on Sub-section 1.1 of Article 6 of the Ministry's Rule for Enforcement of Radio Law of Japan,
2. Use EVMs only after user obtains the license of Test Radio Station as provided in Radio Law of Japan with respect to EVMs, or
3. Use of EVMs only after user obtains the Technical Regulations Conformity Certification as provided in Radio Law of Japan with respect to EVMs. Also, do not transfer EVMs, unless user gives the same notice above to the transferee. Please note that if user does not follow the instructions above, user will be subject to penalties of Radio Law of Japan.

<http://www.tij.co.jp>

【無線電波を送信する製品の開発キットをお使いになる際の注意事項】本開発キットは技術基準適合証明を受けておりません。本製品のご使用に際しては、電波法遵守のため、以下のいずれかの措置を取っていただく必要がありますのでご注意ください。

1. 電波法施行規則第6条第1項第1号に基づく平成18年3月28日総務省告示第173号で定められた電波暗室等の試験設備でご使用いただく。
2. 実験局の免許を取得後ご使用いただく。
3. 技術基準適合証明を取得後ご使用いただく。。

なお、本製品は、上記の「ご使用にあたっての注意」を譲渡先、移転先に通知しない限り、譲渡、移転できないものとします

上記を遵守頂けない場合は、電波法の罰則が適用される可能性があることをご留意ください。

日本テキサス・インスツルメンツ株式会社

東京都新宿区西新宿6丁目24番1号

西新宿三井ビル

<http://www.tij.co.jp>

Texas Instruments Japan Limited

(address) 24-1, Nishi-Shinjuku 6 chome, Shinjuku-ku, Tokyo, Japan

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, enhancements, improvements and other changes to its semiconductor products and services per JESD46, latest issue, and to discontinue any product or service per JESD48, latest issue. Buyers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All semiconductor products (also referred to herein as "components") are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its components to the specifications applicable at the time of sale, in accordance with the warranty in TI's terms and conditions of sale of semiconductor products. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by applicable law, testing of all parameters of each component is not necessarily performed.

TI assumes no liability for applications assistance or the design of Buyers' products. Buyers are responsible for their products and applications using TI components. To minimize the risks associated with Buyers' products and applications, Buyers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI components or services are used. Information published by TI regarding third-party products or services does not constitute a license to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of significant portions of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI components or services with statements different from or beyond the parameters stated by TI for that component or service voids all express and any implied warranties for the associated TI component or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Buyer acknowledges and agrees that it is solely responsible for compliance with all legal, regulatory and safety-related requirements concerning its products, and any use of TI components in its applications, notwithstanding any applications-related information or support that may be provided by TI. Buyer represents and agrees that it has all the necessary expertise to create and implement safeguards which anticipate dangerous consequences of failures, monitor failures and their consequences, lessen the likelihood of failures that might cause harm and take appropriate remedial actions. Buyer will fully indemnify TI and its representatives against any damages arising out of the use of any TI components in safety-critical applications.

In some cases, TI components may be promoted specifically to facilitate safety-related applications. With such components, TI's goal is to help enable customers to design and create their own end-product solutions that meet applicable functional safety standards and requirements. Nonetheless, such components are subject to these terms.

No TI components are authorized for use in FDA Class III (or similar life-critical medical equipment) unless authorized officers of the parties have executed a special agreement specifically governing such use.

Only those TI components which TI has specifically designated as military grade or "enhanced plastic" are designed and intended for use in military/aerospace applications or environments. Buyer acknowledges and agrees that any military or aerospace use of TI components which have **not** been so designated is solely at the Buyer's risk, and that Buyer is solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI has specifically designated certain components as meeting ISO/TS16949 requirements, mainly for automotive use. In any case of use of non-designated products, TI will not be responsible for any failure to meet ISO/TS16949.

Products

Audio	www.ti.com/audio
Amplifiers	amplifier.ti.com
Data Converters	dataconverter.ti.com
DLP® Products	www.dlp.com
DSP	dsp.ti.com
Clocks and Timers	www.ti.com/clocks
Interface	interface.ti.com
Logic	logic.ti.com
Power Mgmt	power.ti.com
Microcontrollers	microcontroller.ti.com
RFID	www.ti-rfid.com
OMAP Applications Processors	www.ti.com/omap
Wireless Connectivity	www.ti.com/wirelessconnectivity

Applications

Automotive and Transportation	www.ti.com/automotive
Communications and Telecom	www.ti.com/communications
Computers and Peripherals	www.ti.com/computers
Consumer Electronics	www.ti.com/consumer-apps
Energy and Lighting	www.ti.com/energy
Industrial	www.ti.com/industrial
Medical	www.ti.com/medical
Security	www.ti.com/security
Space, Avionics and Defense	www.ti.com/space-avionics-defense
Video and Imaging	www.ti.com/video

TI E2E Community

e2e.ti.com