## VBA-4E-G12-ZAJ

c (UL) us 62 CE Spec 2.1


#### Model number

#### VBA-4E-G12-ZAJ


G12 flat module 4 inputs (PNP)

#### Features


- · A/B slave with extended addressing possibility for up to 62 slaves
- One-piece housing with stainless • steel base
- Installation without tools •
- Metal threaded inserts with SPEED-• CON technology
- Flat cable connection with cable pier-• cing technique, variable flat cable guide
- Communication monitoring •
- Inputs for 2-, 3-, and 4-wire sensors •
- **DIN** rail mounting •
- AS-Interface certificate



#### **Electrical connection**



#### Indicating / Operating means





9 Status indication (10)

Addressing socket

1

www.pepperl-fuchs.com fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

# F PEPPERL+FUCHS

### **AS-Interface sensor module**

2

# VBA-4E-G12-ZAJ

Technical data		Function
General specifications		The VPA 4E G10 7* Lie on 40 Interface Lie
Slave type	A/B slave	The VBA-4E-G12-Z*J is an AS-Interface trig-
AS-Interface specification	V3.0	ger module with 4 inputs. 2- and 3-wire sen- sors as well as mechanical contacts can be
Required master specification	≥ V2.1	connected to the plus switching electronic
UL File Number	E223772	inputs.
Functional safety related parameters		The solid housing permits fast mounting wit-
MTTF <sub>d</sub>	410 a	hout tools as well as easy removal without
Mission Time (T <sub>M</sub> )	20 a	tools. The stainless steel shell and the cast
Diagnostic Coverage (DC)	0 %	housing ensure durability and a high protec-
Indicators/operating means		tion category.
LED FAULT	error display; LED red red: communication error or address is 0 red flashing: overload of sensor supply	The connection to the AS-Interface cable is achieved via penetration technology in the
LED PWR	AS-Interface voltage; green LED green: voltage OK flashing green: address 0	integrated flat cable. The insert for the flat cables can be turned in two orientations. All connections to inputs are implemented via
LED IN	switching state (input); 4 LED yellow	metal inserts for high stability. The connection
Electrical specifications		to the sensors is achieved via a M12 x 1 cir-
Rated operating voltage U <sub>e</sub>	26.5 31.6 V from AS-Interface	cular connector with SPEEDCON quick
Rated operating current I <sub>e</sub>	≤ 40 mA (without sensors) / max. 240 mA	locking option.
Protection class		The inputs and the connected sensors are
Surge protection	U <sub>e</sub> : Over voltage category III, safe isolated power supplies (PELV) derived from mains up to 300 V AC line-to-neutral	supplied via the internal power supply of the module (from AS-Interface).
Input		To indicate the current switching state there is
Number/Type	4 inputs for 2- or 3-wire sensors (PNP), DC option 2 inputs for 4-wire sensors (PNP), DC	an LED for each channel fitted to the top of the module.
Supply	from AS-Interface	An LED to indicate the AS-Interface voltage
Voltage	21 31 V	and that the module has an address of 0 is
Current loading capacity	$\leq$ 200 mA, overload and short-circuit protected	available, another indicates errors in the AS-
Input current	$\leq$ 8 mA (limited internally)	Interface communication as well as periphery
Switching point 0 (unattenuated)	according to DIN EN 61131-2 (Type 2) ≤ 2 mA	faults.
1 (attenuated)	≥6 mA	This module can be mounted in any position
Signal delay	< 1 ms (input/AS-Interface)	using three screws or can be snapped onto
Directive conformity		the DIN rail using the stainless steel holder.
Electromagnetic compatibility		
Directive 2014/30/EU	EN 62026-2:2013	Accessories
Standard conformity		VBP-HH1-V3.0-KIT
Degree of protection	EN 60529:2000	AS-Interface Handheld with accessory
Fieldbus standard	EN 62026-2:2013	
Input	EN 61131-2	VAZ-V1-B3
Emitted interference	EN 61000-6-4:2007	Blind plug for M12 sockets
AS-Interface	EN 62026-2:2013	VBP-HH1-V3.0
Noise immunity	EN 61000-6-2:2005 EN 62026-2:2013	AS-Interface Handheld
Programming instructions		AS-Interface Handheid
Profile	S-0.A.2	VAZ-PK-1,5M-V1-G
IO code	0	Adapter cable module/hand-held pro-
ID code	A	gramming device
ID1 code	7	
ID2 code	2 autout	VAZ-CLIP-G12
Data bits (function via AS-Interface) D0	input output	lock for G12 module
D0 D1	IN1 - IN2 -	
D2	IN2 -	
D2 D3	IN4 -	
Parameter bits (programmable via AS-i)		
P0	not used	
P1	Input filter P1 = 0 input filter on, pulse suppression $\leq$ 2 ms	
P2	P1 = 1 input filter off (default settings) Synchronous mode P2 = 0 synchronous mode on P2 = 1 synchronous mode off (default settings)	
P3	not used	
Ambient conditions		
Ambient conditions	-25 70 °C (-13 158 °F)	
Storage temperature	-25 70 °C (-13 185 °F)	
Relative humidity	85 % , noncondensing	
Climatic conditions	For indoor use only	
Altitude	$\leq$ 2000 m above MSL	
Shock and impact resistance	30 g, 11 ms in 6 spatial directions 3 shocks 10 g, 16 ms in 6 spatial directions 1000 shocks	
Vibration resistance	0.75 mm 10 57 Hz , 5 g 57 150 Hz, 20 cycles	
Pollution degree	3	
Mechanical specifications		
		Ι

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



## VBA-4E-G12-ZAJ

Degree of protection	IP67
Connection	cable piercing method flat cable yellow inputs: M12 round connector
Material	
Housing	PBT
Mass	200 g
Tightening torque, cable gland	0.4 Nm
Mounting	Mounting plate

#### Notes

For 4-wire sensors, it is only possible to use plug-in slot IN1 or IN3 for inputs 1+2 or 3+4 (jumpered internally).

Do not connect inputs and outputs, which are supplied via the module from AS-interface or via auxiliary power, with power supply and signal circuits with external potentials.

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

