VBA-4E4A-G12-XEL

Dimensions






Model number

VBA-4E4A-G12-XEL


G12 flat module 4 inputs (PNP) and 4 electronic outputs

Features


- One-piece housing with stainless ٠ steel base
- Installation without tools
- Metal threaded inserts with SPEED-CON technology
- Flat cable connection with cable pier-٠ cing technique, variable flat cable guide
- Communication monitoring, configu-٠ rable
- Inputs for 2- and 3-wire sensors •
- **DIN** rail mounting •
- Sensor supply powered by AUX •
- Input and output connection on each • M12 connector




Electrical connection



Indicating / Operating means







Addressing socket

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

EPPPERL+FUCHS

1

AS-Interface sensor/actuator module

Technical data			
General specifications			
Slave type	A/B slave	A/B slave	
AS-Interface specification	V3.0		
Required master specification	≥ V3.0		
UL File Number	E223772		
Indicators/operating means			
LED FAULT	error display; LED red		
	red: communication error or address is 0 red flashing: overload of sensor power supply or outputs		
LED PWR	AS-Interface voltage; green LED green: voltage OK flashing green: address 0		
LED AUX	ext. auxiliary voltage U _{AUX} ; dual LED green/red green: voltage OK		
	red: reverse voltage	velle	
	switching state (input); 4 LED	yellow	
Electrical specifications			
Auxiliary voltage U _{AU}			
Rated operating voltage U _e	26.5 31.6 V from AS-Interfa	ce	
Rated operating current I _e	≤ 40 mA		
Protection class			
Surge protection	U_{AUX}, U_{in} : Over voltage category III, safe isolated power supplies (PELV) derived from mains up to 300 V AC line-to-neutral		
Input	4 inputs for 0 and wine and		
Number/Type		4 inputs for 2- or 3-wire sensors (PNP), DC	
Supply	from external auxiliary voltage U _{AUX}		
Current loading capacity	≤ 500 mA overload and short-circuit resistant		
Input current	\leq 8 mA (limited internally)		
Switching point	according to DIN EN 61131-2 (Type 2)		
0 (unattenuated)	≤2 mA		
1 (attenuated)	≥ 6 mA		
Signal delay	< 1 ms (input/AS-Interface)		
Output			
Number/Type	4 electronic outputs, PNP, ove		
Supply	from external auxiliary voltage	U _{AUX}	
Current	1 A per output		
Valtana	≥ (U _{AUX} - 0.5 V)		
Voltage	≥ (U _{AUX} - 0.5 V)		
Voltage Directive conformity	≥ (U _{AUX} - 0.5 V)		
•	≥ (U _{AUX} - 0.5 V)		
Directive conformity	≥ (U _{AUX} - 0.5 V) EN 62026-2:2013 EN 61000-6	5-2:2005, EN 61000-6-4:2007	
Directive conformity Electromagnetic compatibility Directive 2014/30/EU		6-2:2005, EN 61000-6-4:2007	
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity	EN 62026-2:2013 EN 61000-6	5-2:2005, EN 61000-6-4:2007	
Directive conformity Electromagnetic compatibility Directive 2014/30/EU		6-2:2005, EN 61000-6-4:2007	
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection Fieldbus standard	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013	6-2:2005, EN 61000-6-4:2007	
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013 EN 61131-2:2007	6-2:2005, EN 61000-6-4:2007	
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection Fieldbus standard Input	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013	6-2:2005, EN 61000-6-4:2007	
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection Fieldbus standard Input Emitted interference AS-Interface	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013 EN 61131-2:2007 EN 61000-6-4:2007		
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection Fieldbus standard Input Emitted interference AS-Interface Noise immunity	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013 EN 61131-2:2007 EN 61000-6-4:2007 EN 62026-2:2013		
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection Fieldbus standard Input Emitted interference AS-Interface Noise immunity Programming instructions	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013 EN 61131-2:2007 EN 61000-6-4:2007 EN 62026-2:2013 EN 61000-6-2:2005 EN 62026		
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection Fieldbus standard Input Emitted interference AS-Interface Noise immunity Programming instructions Profile	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013 EN 61131-2:2007 EN 61000-6-4:2007 EN 62026-2:2013 EN 61000-6-2:2005 EN 62026 S-7.A.7		
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection Fieldbus standard Input Emitted interference AS-Interface Noise immunity Programming instructions Profile IO code	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013 EN 61131-2:2007 EN 61000-6-4:2007 EN 62026-2:2013 EN 61000-6-2:2005 EN 62026 S-7.A.7 7		
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection Fieldbus standard Input Emitted interference AS-Interface Noise immunity Programming instructions Profile IO code ID code	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013 EN 61131-2:2007 EN 61000-6-4:2007 EN 62026-2:2013 EN 61000-6-2:2005 EN 62026 S-7.A.7 7 A		
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection Fieldbus standard Input Emitted interference AS-Interface Noise immunity Programming instructions Profile IO code ID code ID1 code	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013 EN 61131-2:2007 EN 61000-6-4:2007 EN 62026-2:2013 EN 61000-6-2:2005 EN 62026 S-7.A.7 7 A 7		
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection Fieldbus standard Input Emitted interference AS-Interface Noise immunity Programming instructions Profile IO code ID code ID1 code ID2 code	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013 EN 61131-2:2007 EN 61000-6-4:2007 EN 62026-2:2013 EN 61000-6-2:2005 EN 62026 S-7.A.7 7 A 7 7	5-2:2013	
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection Fieldbus standard Input Emitted interference AS-Interface Noise immunity Programming instructions Profile IO code ID code ID1 code ID2 code Data bits (function via AS-Interface)	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013 EN 61131-2:2007 EN 61000-6-4:2007 EN 62026-2:2013 EN 61000-6-2:2005 EN 62026 S-7.A.7 7 A 7 7 input	5-2:2013 output	
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection Fieldbus standard Input Emitted interference AS-Interface Noise immunity Programming instructions Profile IO code ID code ID1 code ID2 code Data bits (function via AS-Interface) D0	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013 EN 61131-2:2007 EN 61000-6-4:2007 EN 62026-2:2013 EN 61000-6-2:2005 EN 62026 S-7.A.7 7 A 7 A 7 IN1	5-2:2013 output OUT1	
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection Fieldbus standard Input Emitted interference AS-Interface Noise immunity Programming instructions Profile IO code ID code ID code ID code ID code Data bits (function via AS-Interface) D0 D1	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013 EN 61131-2:2007 EN 61000-6-4:2007 EN 62026-2:2013 EN 61000-6-2:2005 EN 62026 S-7.A.7 7 A 7 A 7 input IN1 IN2	3-2:2013 output OUT1 OUT2	
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection Fieldbus standard Input Emitted interference AS-Interface Noise immunity Programming instructions Profile IO code ID code ID1 code ID2 code Data bits (function via AS-Interface) D0 D1 D2	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013 EN 61131-2:2007 EN 61000-6-4:2007 EN 62026-2:2013 EN 61000-6-2:2005 EN 62026 S-7.A.7 7 A 7 A 7 input IN1 IN2 IN3	5-2:2013 output OUT1 OUT2 OUT3	
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection Fieldbus standard Input Emitted interference AS-Interface Noise immunity Programming instructions Profile IO code ID code ID code ID code ID code Data bits (function via AS-Interface) D0 D1 D2 D3	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013 EN 61131-2:2007 EN 61000-6-4:2007 EN 62026-2:2013 EN 61000-6-2:2005 EN 62026 S-7.A.7 7 A S-7.A.7 7 A IN1 IN2 IN3 IN4	3-2:2013 output OUT1 OUT2	
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection Fieldbus standard Input Emitted interference AS-Interface Noise immunity Programming instructions Profile IO code ID code ID code ID1 code Data bits (function via AS-Interface) D0 D1 D2	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013 EN 61131-2:2007 EN 61000-6-4:2007 EN 62026-2:2013 EN 61000-6-2:2005 EN 62026 S-7.A.7 7 A 7 input IN1 IN2 IN3 IN4) function communication monitoring P0 = 1 (default settings), moni fails, the outputs are de-energ	5-2:2013 output OUT1 OUT2 OUT3 OUT4 toring = ON, i.e. if communication	
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection Fieldbus standard Input Emitted interference AS-Interface Noise immunity Programming instructions Profile IO code ID code ID code ID code ID code Data bits (function via AS-Interface) D0 D1 D2 D3 Parameter bits (programmable via AS-P0 P1	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013 EN 61131-2:2007 EN 61000-6-4:2007 EN 62026-2:2013 EN 61000-6-2:2005 EN 62026 S-7.A.7 7 A 7 input IN1 IN2 IN3 IN4 j function communication monitoring P0 = 1 (default settings), moni fails, the outputs are de-energy P0 = 0, monitoring = OFF, if cc maintain their condition Input filter P1 = 0 input filter on, pulse sup P1 = 1 input filter off (default s	output OUT1 OUT2 OUT3 OUT4 toring = ON, i.e. if communication ised pommunication fails, the outputs	
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection Fieldbus standard Input Emitted interference AS-Interface Noise immunity Programming instructions Profile IO code ID code ID1 code ID2 code Data bits (function via AS-Interface) D0 D1 D2 D3 Parameter bits (programmable via AS-P0 P1 P2	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013 EN 61131-2:2007 EN 61000-6-4:2007 EN 62026-2:2013 EN 61000-6-2:2005 EN 62026 S-7.A.7 7 A 7 IN1 IN2 IN3 IN4 IN1 IN2 IN3 IN4 IN4 IN4 IN4 IN4 IN4 IN4 IN4 IN5 IN4 IN4 IN5 IN4 IN5 IN4 IN5 IN5 IN5 IN5 IN5 IN5 IN5 IN5 IN5 IN5	output OUT1 OUT2 OUT3 OUT4 toring = ON, i.e. if communication ised promunication fails, the outputs ppression ≤ 2 ms ettings)	
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection Fieldbus standard Input Emitted interference AS-Interface Noise immunity Programming instructions Profile IO code ID code ID code ID code ID code Data bits (function via AS-Interface) D0 D1 D2 D3 Parameter bits (programmable via AS-P0 P1	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013 EN 61131-2:2007 EN 61000-6-4:2007 EN 62026-2:2013 EN 61000-6-2:2005 EN 62026 S-7.A.7 7 A 7 IN1 IN2 IN3 IN4 IN1 IN2 IN3 IN4 IN4 IN4 IN4 IN4 IN4 IN4 IN4 IN5 IN4 IN4 IN5 IN4 IN5 IN4 IN5 IN5 IN5 IN5 IN5 IN5 IN5 IN5 IN5 IN5	output OUT1 OUT2 OUT3 OUT4 toring = ON, i.e. if communication ised prommunication fails, the outputs ppression ≤ 2 ms ettings)	
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection Fieldbus standard Input Emitted interference AS-Interface Noise immunity Programming instructions Profile IO code ID code ID1 code ID2 code Data bits (function via AS-Interface) D0 D1 D2 D3 Parameter bits (programmable via AS-P0 P1 P2	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013 EN 61131-2:2007 EN 61000-6-4:2007 EN 62026-2:2013 EN 61000-6-2:2005 EN 62026 S-7.A.7 7 A 7 IN1 IN2 IN3 IN4 IN1 IN2 IN3 IN4 IN4 IN4 IN4 IN4 IN4 IN4 IN4 IN5 IN4 IN4 IN5 IN4 IN5 IN4 IN5 IN5 IN5 IN5 IN5 IN5 IN5 IN5 IN5 IN5	output OUT1 OUT2 OUT3 OUT4 toring = ON, i.e. if communication ised prommunication fails, the outputs ppression ≤ 2 ms ettings)	
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection Fieldbus standard Input Emitted interference AS-Interface Noise immunity Programming instructions Profile IO code ID code ID1 code ID2 code Data bits (function via AS-Interface) D0 D1 D2 D3 Parameter bits (programmable via AS-P0 P1 P2 P3	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013 EN 61131-2:2007 EN 61000-6-4:2007 EN 62026-2:2013 EN 61000-6-2:2005 EN 62026 S-7.A.7 7 A 7 IN1 IN2 IN3 IN4 IN1 IN2 IN3 IN4 IN4 IN4 IN4 IN4 IN4 IN4 IN4 IN5 IN4 IN4 IN5 IN4 IN5 IN4 IN5 IN5 IN5 IN5 IN5 IN5 IN5 IN5 IN5 IN5	output OUT1 OUT2 OUT3 OUT4 toring = ON, i.e. if communication ised prommunication fails, the outputs ppression ≤ 2 ms ettings)	
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection Fieldbus standard Input Emitted interference AS-Interface Noise immunity Programming instructions Profile IO code ID code ID1 code ID2 code Data bits (function via AS-Interface) D0 D1 D2 D3 Parameter bits (programmable via AS-P0 P1 P2 P3 Ambient conditions	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013 EN 61131-2:2007 EN 61000-6-4:2007 EN 62026-2:2013 EN 61000-6-2:2005 EN 62026 S-7.A.7 7 A 7 input IN1 IN2 IN3 IN4) function communication monitoring P0 = 1 (default settings), moni fails, the outputs are de-energ P0 = 0, monitoring = OFF, if cc maintain their condition Input filter P1 = 0 input filter on, pulse sup P1 = 1 input filter on, pulse sup P1 = 1 input filter off (default s Synchronous mode P2 = 0 synchronous mode on P2 = 1 synchronous mode off not used	output OUT1 OUT2 OUT3 OUT4 toring = ON, i.e. if communication ised prommunication fails, the outputs ppression ≤ 2 ms ettings)	
Directive conformity Electromagnetic compatibility Directive 2014/30/EU Standard conformity Degree of protection Fieldbus standard Input Emitted interference AS-Interface Noise immunity Programming instructions Profile IO code ID code ID code ID1 code ID2 code Data bits (function via AS-Interface) D0 D1 D2 D3 Parameter bits (programmable via AS-P0 P1 P2 P3 Ambient conditions Ambient temperature	EN 62026-2:2013 EN 61000-6 EN 60529:2000 EN 62026-2:2013 EN 61131-2:2007 EN 61000-6-4:2007 EN 62026-2:2013 EN 61000-6-2:2005 EN 62026 S-7.A.7 7 A 7 7 input IN1 IN2 IN3 IN4) function communication monitoring P0 = 1 (default settings), moni fails, the outputs are de-energ P0 = 0, monitoring = OFF, if cc maintain their condition Input filter P1 = 0 input filter on, pulse sup P1 = 1 input filter on, pulse sup P1 = 1 input filter on, pulse sup P1 = 1 synchronous mode on P2 = 0 synchronous mode on P2 = 1 synchronous mode off not used	output OUT1 OUT2 OUT3 OUT4 toring = ON, i.e. if communication ised prommunication fails, the outputs ppression ≤ 2 ms ettings)	

Function

The VBA-4E4A-G12-XEL is an AS-Interface trigger module with 4 inputs and 4 outputs. 2and 3-wire sensors as well as mechanical contacts can be connected to the plus switching electronic inputs. The outputs are electronic outputs which can be energized with max. 24 V DC and 1 A per output.

The solid housing permits fast mounting without tools as well as easy removal without tools. The stainless steel shell and the cast housing ensure durability and a high protection category.

The connection to the AS-Interface calbe and to the external power supply is achieved via penetration technology in the integrated flat cable. The insert for the flat cables can be turned in two orientations.

All connections to inputs and outputs are implemented via metal inserts for high stability. The connection to the sensors/actuators is achieved via a M12 x 1 circular connector with SPEEDCON quick locking option.

The inputs and the connected sensors as well as the outputs and the connected actuators are supplied via an external power source (AUX).

To indicate the current switching state there is an LED for each input fitted to the top of the module.

An LED to indicate the AS-Interface voltage and that the module has an address of 0 is available, another indicates errors in the AS-Interface communication as well as periphery faults. Another LED indicates the external power supply (AUX).

This module can be mounted in any position using three screws or can be snapped onto the DIN rail using the stainless steel holder. An output overload is reported to the AS-Interface master via the function "periphery fault". The communcation with the AS-Interface remains intact.

Accessories

VBP-HH1-V3.0-KIT

AS-Interface Handheld with accessory

VAZ-V1-B3

Blind plug for M12 sockets

VBP-HH1-V3.0 AS-Interface Handheld

VAZ-PK-1,5M-V1-G Adapter cable module/hand-held programming device

VAZ-CLIP-G12 lock for G12 module

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.co



2

www.pepperl-fuchs.com

VBA-4E4A-G12-XEL

Altitude	\leq 2000 m above MSL	
Shock and impact resistance	30 <i>g</i> , 11 ms in 6 spatial directions 3 shocks 10 <i>g</i> , 16 ms in 6 spatial directions 1000 shocks	
Vibration resistance	0.75 mm 10 57 Hz , 5 g 57 150 Hz, 20 cycles	
Pollution degree	3	
Mechanical specifications		
Degree of protection	IP67	
Connection	Cable piercing method flat cable yellow/flat cable black inputs/outputs: M12 round connector	
Material		
Housing	PBT	
Mass	200 g	
Tightening torque, cable gland	0.4 Nm	
Mounting	Mounting plate	

Notes

Do not connect inputs and outputs, which are supplied via the module from AS-interface or via auxiliary power, with power supply and signal circuits with external potentials.

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" USA: +1 330 486 0001

Pepperl+Fuchs Group www.pepperl-fuchs.com

fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

